

# BACnet® TESTING LABORATORIES INTERIM TEST SPECIFICATION

To Be Used with Test Package 16.0 Version 5 October 4, 2019

Approved by the BTL Working Group on September 9, 2019. Approved by the BTL Working Group Voting Members on MMM XX, 2019. Published on MMM XX, 2019.

#### **Foreward**

The purpose of this document is to define interim tests and other test package changes made to support testing of a device that supports functionality currently not covered in the released BTL Test Package. This document should be applied and used with BTL Test Package 16.0.

Vendors who are planning to submit a device for testing and who implement Protocol\_Revision 17 and higher, or which contain functionality not covered by the Official Test Package, should use this Interim Test document.

Please note that if the device contains functionality not yet covered by the official Test Package, nor by the Interim Tests document, development of new tests may be required for your device. Please contact the BTL Manager before submitting your device for testing to ensure you are aware of all tests that will need to be applied to your device.

The changes in this document are for interim use only and may or may not be used as documented here when the final changes are applied to the next Test Package revision. Devices tested using this interim test document shall be recalled for updated testing when the next revision of test package is released that includes the topics covered here.

In the following document, language to be added to existing clauses of ANSI/ASHRAE 135.1-2013 or any part of the Test Package 16.0 are indicated through the use of *italics*, while deletions are indicated by strikethrough. Where entirely new sections are proposed to be added, plain type is used throughout.

# **Table of Contents**

BTL CHECK	KLIST AND BTL TEST PLAN CHANGES	4
3.56	Network Port Object	5
3.58	Elevator Group object	
3.59	Lift Object	
3.60	Escalator Object	
4.27	Data Sharing - Life Safety View - A	
4.28	Data Sharing - Life Safety Advanced View - A	
4.29	Data Sharing - Life Safety Modify - A	
4.30	Data Sharing - Life Safety Advanced Modify - A	
4.31	Data Sharing - Access Control View - A	
4.32	Data Sharing - Access Control Advanced View - A	22
4.33	Data Sharing - Access Control Modify - A	
4.34	Data Sharing - Life Safety Advanced Modify - A	
4.35	Data Sharing - Access Control User Configuration - A	
4.37	Data Sharing - Access Control Site Configuration - A	
4.40	Data Sharing - Access Control Access Door - A	
4.41	Data Sharing - Access Control Credential Data Input - A	
4.43	Data Sharing - Lighting Output - A	
4.44	Data Sharing - Lighting Output Status - A	
4.45	Data Sharing - Advanced Lighting Output - A	
4.48	Data Sharing - Lighting Output Management - A	
4.49	Data Sharing - Lighting View - A	
4.50	Data Sharing - Lighting Advanced View - A	38
4.51	Data Sharing - Lighting Modify - A	
4.52	Data Sharing - Lighting Advanced Modify - A	
5.27	Alarm and Event Management - Life Safety View Notifications - A	
5.28	Alarm and Event Management - Life Safety Advanced View Notifications - A	
5.29	Alarm and Event Management - Life Safety View Modify - A	
5.30	Alarm and Event Management - Life Safety Advanced View Modify - A	
5.31	Alarm and Event Management - Access Control - A	
5.33	Alarm and Event Management - Access Controls Advanced View Notifications - A	
5.34	Alarm and Event Management - Access Control View Modify - A	
5.35	Alarm and Event Management - Access Control Advanced View Modify - A	
8.30	Device Management – Slave Proxy - B	
9.4	BACnet/IP – Annex J - BBMD	
10.7	Network Management - BBMD Configuration - B	
	•	
BTL SPECII	FIED TESTS CHANGES	62
7.3.2.X43	Network Port Object Tests	63
7.3.2.X4	ů	
7.3.2.X4		
7.3.2.X4	* * *	
	Present_Value	64
72237451		
	Linking of Elevator Group Object Tests	
7.3.2.X4	1 1 7 6 5	
7.3.2.X4		
7.3.2.X4		
7.3.2.X4	5.1.4 Linking of Landing_Call_Control Property Test	65
7.3.2.X46.1	Escalator Object Tests	66
7.3.2.X4	6.1.1 Elevator_Group property of Escalator Object linking with Group_Members property of	
	Elevator Group Object	66
7.3.2.X4		66

7.3.2.X46.1.3	Passenger_Alarm and Fault_Signals Tracking Test	67
7.3.2.X46.1.4	Escalator_Mode Tracking Test	
7.3.2.X46.1.6	Energy_Meter_Ref Property Test	69
7.3.2.X46.1.7	CHANGE_OF_STATE for Passenger_Alarm (ConfirmedEventNotification)	69
7.3.2.X46.1.8	CHANGE_OF_STATE for Passenger_Alarm (UnconfirmedEventNotification)	70
7.3.2.X47.1	Lift Object Tests	71
7.3.2.X47.1.1	Elevator_Group property of Lift Object linking with Group_Members property of Elevator	ator
	Group Object	
7.3.2.X47.1.2	Car_Moving_Direction and Car_Assigned_Direction Tracking Test	71
7.3.2.X47.1.4	Car_Position and Next_Stopping_Floor Tracking Test	73
7.3.2.X47.1.5	Passenger_Alarm and Fault_Signals Tracking Test	
7.3.2.X47.1.6	Making_Car_Call, Car_Mode & Car_Door_Command Tracking Test	
7.3.2.X47.1.7	Assigned_Landing_Call and Registered_Car_Call Tracking Test	
7.3.2.X47.1.8	Car_Door_Zone and Car_Load Tracking Test	
7.3.2.X47.1.9	Energy_Meter and Car_Drive_Status Tracking Test	
7.3.2.X47.1.10		
7.3.2.X47.1.11		
7.3.2.X47.1.12	<i>C</i>	
7.3.2.X47.1.13	C 11 C- 1 1	
7.3.2.X47.1.14	6 · · · · · · · · · · · · · · · · · · ·	
	Registered_Car_Call properties	
7.3.2.X47.1.15	$\mathcal{C}_{\mathcal{I}} = \mathcal{C}_{\mathcal{I}} = \mathcal{C}_{\mathcal{I}}$	
7.3.2.X47.1.16		
7.3.2.X47.1.17		
	Elevator Group	81
8.5.X1 CH	ANGE_OF_RELIABILITY Tests	82
8.5.X1.15	Change_Of_Reliability FAULT-to-FAULT transitions in FAULT_LISTED	
9.18.1 Po	sitive ReadProperty Service Execution Tests	
9.18.1 Po	ReadProperty of the Network Port Object using the Unknown Instance	
	, ,	
14.3 Bro	padcast Distribution Table Operations	84
14.3.X1	Write-BDT service is required to return Write-BDT-NAK	
14.3.X2	Broadcast-Distribution-Table Holds at Least 5 Entries	
14.3.X3	BBMD_Broadcast_Distribution_Table Holds at Least 5 Entries	84
14.6 For	eign Device Management	85
14.6.X1	Holds at Least 5 Foreign Device Registrations	
14.6.X2	Negative Foreign Device Registration when FD_Supported is FALSE	

# **BTL Checklist and BTL Test Plan Changes**

This section of the document contains interim changes to the BTL Checklist and the BTL Test Plan documents to support testing of products with functionality outside the scope of the official test plan.

This section is ordered the same as the BTL Checklist and BTL Test Plan documents to allow easy navigation of the material.

All test changes can be found in the next major section.

# 3.56 Network Port Object

A device including a Network Port object must claim Protocol\_Revision 17 or higher and comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace Network Port Object section]

Support	Listing	Option	
Net	Network Port Object		
	R	Base Requirements	
	S	Supports writable Out_Of_Service properties	

# **Test Plan Changes**

[In BTL Test Plan, replace section 3.56 Network Port Object]

#### 3.56 Network Port Object

#### 3.56.1 Base Requirements

Base requirements must be met by any IUT that can contain Network Port objects.

BTL	BTL - 7.3.2.X43.1 - Network Port ACTIVATE_CHANGES test		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	- 7.3.2.X43.2 - Network	Port non-volatility properties test	
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	BTL - 9.18.X5 - ReadProperty of the Network Port Object using the Unknown Instance		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 3.56.2 Supports writable Out\_Of\_Service properties

The Out\_Of\_Service property in Network Port objects contained in the IUT is either writable or can be modified by any other means.

BTL - 7.3.2.X43.3 - Out_Of_Service, Status_Flags, and Reliability test for an Object that does not contain Present_Value		
	Test Conditionality	If this property is writable, this test must be executed.
	<b>Test Directives</b>	This test shall be applied to a Network Port object.
	<b>Testing Hints</b>	

# 3.58 Elevator Group object

A device including an Elevator Group object must claim Protocol\_Revision 18 or higher and comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace Elevator Group Object section]

Support	Listing	Option
Eleva	tor Group	
	R	Base Requirements
	R	Supports Group_Members property
	О	Supports Landing_Call_Control property

# **Test Plan Changes**

[In BTL Test Plan, replace section 3.58 Elevator Group Object]

#### 3.58 Elevator Group Object

#### 3.58.1 Base Requirements

The object contains Machine\_Room\_ID Property.

BTL -	BTL - 7.3.2.X45.1.1 - Machine_Room_ID property linking with the Positive_Integer_Value Object		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

#### 3.58.2 Supports Group\_Members Property

The object contains a Group\_Members Property.

# BTL - 7.3.2.X45.1.2 - Linking of Lift Objects under Group\_Members property of the Elevator Group Object Test Conditionality Must be executed if HTT supports Lift object

	lest Conditionality	Must be executed if 101 supports Lift object.		
	<b>Test Directives</b>			
	<b>Testing Hints</b>			
BTL -	BTL - 7.3.2.X45.1.3 - Linking of Escalator Objects under Group_Members property of the Elevator			
Group	Group Object			
	Test Conditionality	Must be executed if IUT supports Escalator object.		
	<b>Test Directives</b>			
	<b>Testing Hints</b>			

# 3.58.3 Supports Landing\_Call\_Control Property

The object contains a Landing\_Call\_Control Property.

BTL - 7.3.2.X45.1.4 - Linking of Landing_Call_Control Property Test		
	Test Conditionality	Must be executed.
	Test Directives	
	<b>Testing Hints</b>	

# 3.59 Lift Object

A device including a Lift object must claim Protocol\_Revision 18 or higher and must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, add new Lift section in existing 3]

Support	Listing	Option
	Object	
LIII		Daga Daguiramento
	R	Base Requirements
	S	Supports writable Out_Of_Service properties
	S	Supports Landing_Door_Status and Car_Door_Status properties
	О	Supports Making_Car_Call, and Register_Car_Call properties
	О	Supports BACnetARRAY Properties related to the doors of a car
	О	Supports Car_Position and Next_Stopping_Floor properties
	О	Supports Assigned_Landing_Calls, Making_Car_Call and Registered_Car_Call properties
	О	Supports Energy_Meter_Ref and Energy_Meter properties
	О	Supports Higher_Deck and Lower_Deck properties
	О	Supports Reliability_Evaluation_Inhibit property
	0	Supports Reliability Evaluation
	0	Supports CHANGE_OF_STATE event algorithm with Passenger_Alarm property
	0	Supports writable Assigned_Landing_Calls property
	О	Supports FAULT-to-FAULT transitions in FAULT_LISTED

# **Test Plan Changes**

[In BTL Test Plan, replace section 3.59 Lift Object]

#### 3.59 Lift Object

#### 3.59.1 Base Requirements

Base requirements must be met by any IUT that can contain Lift objects.

BTL - 7.3.2.X47.1.1 - Elevator_Group property of Lift Object linking with Group_Members property of Elevator Group Object.		
Test Conditionality	Must be executed.	
Test Directives		
Testing Hints		

# 3.59.2 Supports writable Out\_Of\_Service properties

The Out\_Of\_Service property in Lift objects contained in the IUT is either writable or can be modified by any other means.

DOT			
	BTL - 7.3.2.X43.3 - Out_Of_Service, Status_Flags, and Reliability test for an Object that does not		
conta	in Present_Value		
	Test Conditionality	If this property is writable, this test must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	- 7.3.2.X47.1.2 - Car M	oving_Direction and Car_Assigned_Direction Tracking Test	
	Test Conditionality	If Out Of Service property is either writable or can be modified by other	
		means and if any of these properties are present, this test must be	
		executed.	
	Test Directives	Checated.	
	Testing Hints		
DTI		Status and Landing Door Status Tracking Test	
BIL		or_Status and Landing_Door_Status Tracking Test	
	Test Conditionality	If Out_Of_Service property is either writable or can be modified by other	
		means and if any of these properties are present, this test must be	
		executed.	
	Test Directives		
	<b>Testing Hints</b>		
BTL	- 7.3.2.X47.1.4 - Car_Po	sition and Next_Stopping_Floor Tracking Test	
	Test Conditionality	If Out Of Service property is either writable or can be modified by other	
		means and if any of these properties are present, this test must be	
		executed.	
	Test Directives		
	Testing Hints		
PTI		ger_Alarm and Fault_Signals Tracking Test	
DIL		If Out Of Service property is either writable or can be modified by other	
	Test Conditionality		
		means and if any of these properties are present, this test must be	
	T	executed.	
	Test Directives		
	<b>Testing Hints</b>		
BTL	- 7.3.2.X47.1.6 - Making		
	Test Conditionality	If Out_Of_Service property is either writable or can be modified by other	
		means and if any of these properties are present, this test must be	
		executed.	
	Test Directives		
	<b>Testing Hints</b>		
BTL		d_Landing_Call and Registered_Car_Call Tracking Test	
	Test Conditionality	If Out Of Service property is either writable or can be modified by other	
		means and if any of these properties are present, this test must be	
		executed.	
	Test Directives		
	Testing Hints		
RTI		oor_Zone and Car_Load Tracking Test	
DIL		If Out Of Service property is either writable or can be modified by other	
	Test Conditionality		
		means and if any of these properties are present, this test must be	
	T (D)	executed.	
	Test Directives		
	<b>Testing Hints</b>		
BTL	- 7.3.2.X47.1.9 - Energy	_Meter and Car_Drive_Status Tracking Test	

Test Conditionality	If Out_Of_Service property is either writable or can be modified by other means and if any of these properties are present, this test must be executed.
<b>Test Directives</b>	
<b>Testing Hints</b>	

#### 3.59.3 Supports Making\_Car\_Call and Register\_Car\_Call Properties

Either of the Making\_Car\_Call, Register\_Car\_Call properties in at least one Lift object are present.

BTL -	BTL - 7.3.2.X47.1.10 - Making_Car_Call and Registered_Car_Call Tests		
	<b>Test Conditionality</b>	This test must be executed if Making_Car_Call and Registered_Car_Call	
		properties are present.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

#### 3.59.4 Supports BACnetARRAY Properties related to the doors of a car

BACnetARRAY properties related to the doors of a car are present in at least one Lift object.

BTL	BTL - 7.3.2.X47.1.11 - Array Size of the Lift Object properties based on car door size		
	Test Conditionality	This test must be executed if any of the BACnetARRAY properties	
	-	Car_Door_Text, Assigned Landing Calls, Making Car Call,	
		Registered Car Call, Car Door Status, Car Door Command and	
		Landing_Door_Status are present.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

#### 3.59.5 Supports Landing\_Door\_Status and Car\_Door\_Status Properties

The Landing\_Door\_Status property in at least one Lift object is present.

BTL - 7.3.2.X47.1.12 - Landing_Door_Status Tracks Car_Door_Status Test		
	Test Conditionality	This test must be executed if Landing_Door_Status property is present.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

#### 3.59.6 Supports Car\_Position and Next\_Stopping\_Floor Properties

Either of the Car\_Position, Next\_Stopping\_Floor property in at least one Lift object is present.

BTL	BTL - 7.3.2.X47.1.13 - Highest Universal floor number linking to Car_Position and		
Next_	Next_Stopping_Floor properties		
	Test Conditionality	This test must be executed if Car_Position and Next_Stopping_Floor properties are present. If any property is not present, the respective step shall be skipped	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 3.59.7 Supports Assigned\_Landing\_Calls, Making\_Car\_Call and Registered\_Car\_Call Properties

Either of the Assigned\_Landing\_Calls, Making\_Car\_Call and Register\_Car\_Call property in at least one Lift object is present.

BTL - 7.3.2.X47.1.14 Highest Universal floor number linking to Assigned_Landing_Calls, Making_Car_Call and Registered_Car_Call properties		
Test Condi	tionality	This test must be executed if Assigned_Landing_Calls, Making_Car_Call and Registered_Car_Call properties are present. If any property is not present, the respective step shall be skipped
Test Direct	ives	
Testing Hir	nts	

#### 3.59.8 Supports Energy\_Meter\_Ref and Energy\_Meter Properties

The Energy\_Meter\_Ref and Energy\_Meter property in at least one Lift object is present.

BTL -	BTL - 7.3.2.X47.1.15 Energy_Meter_Ref Property Tests	
	<b>Test Conditionality</b>	This test must be executed if Energy Meter Ref and Energy Meter
		property is present
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

#### 3.59.9 Supports Higher\_Deck and Lower\_Deck Properties

The Higher\_Deck and Lower\_Deck properties in at least one Lift object is present.

BTL	BTL - 7.3.2.X47.1.16 Higher_Deck and Lower_Deck Tests	
	Test Conditionality	This test must be executed if Higher_Deck and Lower_Deck properties
		are present
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

#### 3.59.10 Supports Reliability\_Evaluation\_Inhibit Property

The IUT contains, or can be made to contain, a Reliability\_Evaluation\_Inhibit property that is configurable to a value of TRUE.

BTL	BTL - 7.3.1.X8.1 - Reliability_Evaluation_Inhibit Test	
	Test Conditionality	If no object exists in the IUT for which fault conditions can be generated,
		then this test shall be skipped.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
BTL	BTL - 7.3.1.X8.2 - Reliability_Evaluation_Inhibit Summarization Test	
	Test Conditionality	If no object exists in the IUT for which fault conditions can be
	-	generated, then this test shall be skipped.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

#### 3.59.11 Supports Reliability Evaluation

The IUT contains, or can be made to contain, a Lift object that can generate ConfirmedEventNotifications and UnconfirmedEventNotifications with an Event\_Type of CHANGE\_OF\_RELIABILITY.

	BTL - 8.4.X1.13 Change_Of_Reliability with FAULT_LISTED Algorithm (ConfirmedEventNotification)		
	Test Conditionality	This test must be executed	
	<b>Test Directives</b>		
	Testing Hints		
BTL	BTL - 8.4.X1.14 Change_Of_Reliability with FAULT_LISTED Algorithm		
(Unc	(UnconfirmedEventNotification)		
	Test Conditionality	This test must be executed	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 3.59.12 Supports CHANGE\_OF\_STATE event algorithm with Passenger\_Alarm property

Intrinsic event algorithm is supported using Passenger\_Alarm property in at least one Lift object.

BTL	BTL - 7.3.2.X46.1.8 CHANGE_OF_STATE for Passenger_Alarm (ConfirmedEventNotification)	
	Test Conditionality	This test must be executed if the object under test supports
		CHANGE_OF_STATE event algorithm with Passenger_Alarm property
		writable or can be modified by any other means.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
BTL	BTL - 7.3.2.X46.1.9 CHANGE_OF_STATE for Passenger_Alarm (UnconfirmedEventNotificatio	
	Test Conditionality	This test must be executed if the object under test supports
	-	CHANGE_OF_STATE event algorithm with Passenger_Alarm property
		writable or can be modified by any other means.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

#### 3.59.13 Supports writable Assigned Landing Calls Property

The Assigned\_Landing\_Calls property is present in at least one Lift object.

BTL - 7.3.2.X47.1.17 - Linking of Assigned_Landing_Calls property of Lift Object to Landing_Calls property of Elevator Group		
	Test Conditionality	This test must be executed if Assigned_Landing_Calls is writable.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

# 3.59.14 Supports FAULT-to-FAULT transitions in FAULT\_LISTED

These requirements must be met by any IUT that can contain more than one element or different values in the Fault\_Signals property in any of its Lift objects.

BTL - 8.5.X1.15 - Change_Of_Reliability FAULT-to-FAULT transitions in FAULT_LISTED		
Test C	onditionality	Must be executed.
Test D	irectives	
Testing	g Hints	

# 3.60 Escalator Object

A device including an Escalator object must claim Protocol\_Revision 18 or higher and must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace Escalator Object section]

Support	Listing	Option
Esca	alator Obje	et
	R	Base Requirements
	S	Supports writable Out_Of_Service properties
	S	Supports Escalator_Mode property
	О	Supports Energy_Meter_Ref property
	О	Supports CHANGE_OF_STATE event algorithm with Passenger_Alarm property
	0	Supports Reliability_Evaluation_Inhibit property
	O	Supports FAULT-to-FAULT transitions in FAULT_LISTED

#### **Test Plan Changes**

[In BTL Test Plan, replace section 3.60 Escalator Object]

#### 3.60 Escalator Object

#### 3.60.1 Base Requirements

Base requirements must be met by any IUT that can contain Escalator objects.

BTL - 7.3.2.X46.1.1 Elevator_Group property of Escalator Object linking with Group_Members			
prope	property of Elevator Group Object		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 3.60.2 Supports writable Out\_Of\_Service properties

The Out\_Of\_Service property in Escalator objects contained in the IUT is either writable or can be modified by any other means.

	BTL - 7.3.2.X43.3 - Out_Of_Service, Status_Flags, and Reliability test for an Object that does not		
conta	in Present_Value		
	Test Conditionality	If this property is writable, this test must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	BTL - 7.3.2.X46.1.2 - Energy_Meter, Power_Mode and Operation_Direction Tracking Test		
	Test Conditionality	This test must be executed if Energy_Meter or Power_Mode properties	
		are present.	
	<b>Test Directives</b>		

	<b>Testing Hints</b>		
BTL	BTL - 7.3.2.X46.1.3 - Passenger_Alarm and Fault_Signals Tracking Test		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	- 7.3.2.X46.1.4 - Escalato	or_Mode Tracking Test	
	Test Conditionality	This test must be executed if Escalator_Mode property is present.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

#### 3.60.3 Supports Escalator\_Mode Property

The Escalator\_Mode property in at least one Escalator object is present.

BTL - 7.3.2.X46.1.5 - Operation_Direction Tracks Escalator_Mode Test		
	Test ConditionalityMust be executed.	
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

#### 3.60.4 Supports Energy Meter Ref Property

The Energy\_Meter\_Ref property in at least one Escalator object is present.

BTL	BTL - 7.3.2.X46.1.6 - Energy_Meter_Ref Property Test		
<b>Test Conditionality</b> This test must be executed if both Energy_Meter_Ref and Energy_Meter_Re		This test must be executed if both Energy_Meter_Ref and Energy_Meter	
		properties are present.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 3.60.5 Supports CHANGE\_OF\_STATE event algorithm with Passenger Alarm property

Intrinsic event algorithm is supported using Passenger\_Alarm property in at least one Escalator.

BTL	BTL - 7.3.2.X46.1.7 - CHANGE_OF_STATE for Passenger_Alarm (ConfirmedEventNotification)		
	Test Conditionality	This test must be executed if the object under test supports	
		CHANGE_OF_STATE event algorithm with Passenger_Alarm property	
		writable or can be modified by any other means.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	BTL - 7.3.2.X46.1.8 - CHANGE_OF_STATE for Passenger_Alarm		
(Unco	(UnconfirmedEventNotification)		
	Test Conditionality	This test must be executed if the object under test supports	
		CHANGE_OF_STATE event algorithm with Passenger_Alarm property	
		writable or can be modified by any other means.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

#### 3.60.6 Supports Reliability\_Evaluation\_Inhibit Property

The IUT contains, or can be made to contain, a Reliability\_Evaluation\_Inhibit property that is configurable to a value of TRUE.

BTL - 7.3.1.X8.1 - Reliability_Evaluation_Inhibit Test

	Test Conditionality	If no object exists in the IUT for which fault conditions can be generated,
	then this test shall be skipped.	
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
BTL	- 7.3.1.X8.2 - Reliability	_Evaluation_Inhibit Summarization Test
	Test Conditionality	If no object exists in the IUT for which fault conditions can be generated,
	-	then this test shall be skipped.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	

# 3.60.7 Supports FAULT-to-FAULT transitions in FAULT\_LISTED

These requirements must be met by any IUT that can contain more than one element or different values in the Fault\_Signals property in any of its Escalator objects.

BTL	BTL - 8.5.X1.15 - Change_Of_Reliability FAULT-to-FAULT transitions in FAULT_LISTED		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 4.27 Data Sharing - Life Safety View - A

Devices claiming support for Data Sharing - Life Safety View - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checlist, modify section Data Sharing - Life Safety View - A]

Dat	Data Sharing - Life Safety View - A		
	R <sup>1</sup>	Base Requirements	
	R	Supports DS-RP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan replace section 4.27 Data Sharing - Life Safety View - A]

#### 4.27 Data Sharing - Life Safety View - A

#### 4.27.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-	135.1-2013 - 8.18.3 - Reading and Presenting Properties		
	Test Conditionality	Must be executed if the IUT does not support DS-LSAV-A.	
	<b>Test Directives</b>	Repeat the test for <u>each</u> of the standard object types and associated	
		properties specified by DS-LSV-A.	
	<b>Testing Hints</b>		

#### 4.27.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verify Checklist		
	Test Conditionality	Must be executed.
	Test Directives	Verify that the IUT claims support for DS-RP-A.
	Testing Hints	

# 4.28 Data Sharing - Life Safety Advanced View - A

Devices claiming support for Data Sharing - Life Safety Advanced View - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section DS-LSAV-A]

Dat	Data Sharing - Life Safety Advanced View - A	
	R <sup>1</sup>	Base Requirements
	R	Supports DS-RP-A
	<sup>1</sup> Contact BTL for interim tests for this BIBB.	

#### **Test Plan Changes**

[In BTL Test Plan, replace 4.28 Data Sharing - Life Safety Advanced View - A]

#### 4.28 Data Sharing - Life Safety Advanced View - A

#### 4.28.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	35.1-2013 - 8.18.3 - Reading and Presenting Properties	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Repeat the test for <u>all</u> standard objects and properties identified in DS-LSAV-A.
		For properties that contain a CHOICE construct, the IUT shall be capable of reading and presenting each of the forms of the datatype as defined in the IUT's claimed protocol revision.  Full accuracy presentation is not required throughout the IUT, but there should be at least one place provided by the IUT that allows the presentation of each property to be presented in such a way that the presentation requirements of DS-LSAV-A are met.
	<b>Testing Hints</b>	presentation requirements of DS-LSA V-A are free.

#### 4.28.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verif	ify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.
	<b>Testing Hints</b>	

# 4.29 Data Sharing - Life Safety Modify - A

Devices claiming support for Data Sharing - Life Safety Modify - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Life Safety Modify - A]

Data	Data Sharing - Life Safety Modify - A		
	$R^{1}$	Base Requirements	
	R	Supports DS-WP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.29 Data Sharing - Life Safety Modify - A]

#### 4.29 Data Sharing - Life Safety Modify - A

#### 4.29.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	35.1-2013 - 8.22.4 - Accepting Input and Modifying Properties	
	Test Conditionality	Must be executed if the IUT does not support DS-LSAM-A.
	Test Directives	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.  Repeat for <u>each</u> of the required properties listed in the BIBB definition,
		except for those properties which are commandable.  Repeat the test for a variety of values that cover the range of values required by the "Minimum Writable Value Ranges" table in the DS-M-A BIBB definition.
	<b>Testing Hints</b>	
135.1	-2013 - 8.22.5 - Acceptin	g Input and Commanding/Relinquishing Properties
	Test Conditionality	Must be executed if the IUT does not support DS-LSAM-A.
	<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .
	<b>Testing Hints</b>	

#### 4.29.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	fy Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.
	<b>Testing Hints</b>	

# 4.30 Data Sharing - Life Safety Advanced Modify - A

Devices claiming support for Data Sharing - Life Safety Advanced Modify - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Life Safety Advanced Modify - A]

Dat	Data Sharing - Life Safety Advanced Modify - A		
	R⁴	Base Requirements	
	R	Supports DS-WP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[Replace Test Plan Entry 4.30 Data Sharing - Life Safety Advanced Modify - A]

#### 4.30 Data Sharing - Life Safety Advanced Modify - A

#### 4.30.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	35.1-2013 - 8.22.4 - Accepting Input and Modifying Properties	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.  Repeat for <u>each</u> of the required properties listed in the BIBB definition,
		except for those properties which are commandable.  Repeat the test for a variety of values that cover the range of values required by the "Minimum Writable Value Ranges" table in the DS-M-A BIBB definition.
	<b>Testing Hints</b>	
135.1	-2013 - 8.22.5 - Acceptin	g Input and Commanding/Relinquishing Properties
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .
	<b>Testing Hints</b>	

#### 4.30.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	fy Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.
	<b>Testing Hints</b>	

# 4.31 Data Sharing - Access Control View - A

Devices claiming support for Data Sharing - Access Control View - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control View - A]

Data	Data Sharing - Access Control View - A		
	R <sup>1</sup>	Base Requirements	
	R	Supports DS-RP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.31 Data Sharing - Access Control View - A]

#### 4.31 Data Sharing - Access Control View - A

#### 4.31.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-20	135.1-2013 - 8.18.3 - Reading and Presenting Properties		
T	<b>Test Conditionality</b> Must be executed if the IUT does not support DS-ACAV-A.		
T	Test Directives	Repeat the test for each of the standard object types and associated	
		properties specified by DS-ACV-A.	
T	Testing Hints		

#### 4.31.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verify Checklist		
	Test Conditionality	Must be executed.
	Test Directives	Verify that the IUT claims support for DS-RP-A.
	Testing Hints	

# 4.32 Data Sharing - Access Control Advanced View - A

Devices claiming support for Data Sharing - Access Control Advanced View - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control Advanced View - A]

Data	Data Sharing - Access Control Advanced View - A		
	R⁴	Base Requirements	
	R	Supports DS-RP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plans Changes**

[In BTL Test Plan, replace section 4.32 Data Sharing - Access Control Advanced View - A]

#### 4.32 Data Sharing - Access Control Advanced View - A

#### 4.32.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	135.1-2013 - 8.18.3 - Reading and Presenting Properties	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Repeat the test for <u>all</u> standard objects and properties identified in DS-ACAV-A.
		For properties that contain a CHOICE construct, the IUT shall be capable of reading and presenting each of the forms of the datatype as defined in the IUT's claimed protocol revision.
		Full accuracy presentation is not required throughout the IUT, but there should be at least one place provided by the IUT that allows the presentation of each property to be presented in such a way that the presentation requirements of DS-ACAV-A are met.
	<b>Testing Hints</b>	

#### 4.32.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verify Checklist		
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.
	<b>Testing Hints</b>	

# 4.33 Data Sharing - Access Control Modify - A

Devices claiming support for Data Sharing - Access Control Modify - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control Modify - A]

Dat	Data Sharing - Access Control Modify - A	
	$R^{1}$	Base Requirements
	R	Supports DS-WP-A
	<sup>1</sup> Contact BTL for interim tests for this BIBB.	

#### **Test Plans Changes**

[In BTL Test Plan, replace section 4.32 Data Sharing - Access Control Advanced View - A]

#### 4.33 Data Sharing - Access Control Modify - A

#### 4.33.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	135.1-2013 - 8.22.4 - Accepting Input and Modifying Properties	
	Test Conditionality	Must be executed if the IUT does not support DS-ACAM-A.
	<b>Test Directives</b>	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.
		Repeat for <u>each</u> of the required properties listed in the BIBB definition, except for those properties which are commandable.
		Repeat the test for a variety of values that cover the range of values
		required by the "Minimum Writable Value Ranges" table in the DS-M-A BIBB definition.
	<b>Testing Hints</b>	
135.1	-2013 - 8.22.5 - Acceptin	g Input and Commanding/Relinquishing Properties
	Test Conditionality	Must be executed if the IUT does not support DS-ACAM-A.
	<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .
	<b>Testing Hints</b>	

#### 4.33.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verify	Verify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	Testing Hints		

# 4.34 Data Sharing - Life Safety Advanced Modify - A

Devices claiming support for Data Sharing - Access Control Advanced Modify - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control Advanced Modify - A]

Data	Data Sharing - Access Control Advanced Modify - A		
	R <sup>‡</sup>	Base Requirements	
	R	Supports DS-WP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.34 Data Sharing - Life Safety Advanced Modify - A]

#### 4.34 Data Sharing - Life Safety Advanced Modify - A

#### 4.34.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	5.1-2013 - 8.22.4 - Accepting Input and Modifying Properties		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.  Repeat for each of the required properties listed in the BIBB definition,	
		except for those properties which are commandable.  Repeat the test for a variety of values that cover the range of values required by the "Minimum Writable Value Ranges" table in the DS-M-A BIBB definition.	
	<b>Testing Hints</b>		
135.1	-2013 - 8.22.5 - Acceptin	g Input and Commanding/Relinquishing Properties	
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .	
	<b>Testing Hints</b>		

#### 4.34.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	rify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	<b>Testing Hints</b>		

# 4.35 Data Sharing - Access Control User Configuration - A

Devices claiming support for Data Sharing - Access Control User Configuration - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control User Configuration - A]

Data	Data Sharing - Access Control User Configuration - A		
	R <sup>‡</sup>	Base Requirements	
	R	Supports DS-RP-A	
	R	Supports DS-WP-A	
	R	Supports DM-OCD-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.35 Data Sharing - Access Control User Configuration - A]

#### 4.35 Data Sharing - Access Control User Configuration - A

#### 4.35.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-2013 - 8.18.3 - Reading and Presenting Properties		
Test Conditionality	Must be executed.	
Test Directives	Repeat the test for <u>each</u> of the standard object types and associated	
	properties specified by DS-ACUC-A.	
<b>Testing Hints</b>		
135.1-2013 - 8.22.4 - Accep	oting Input and Modifying Properties	
Test Conditionality	Must be executed.	
Test Directives	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.	
	Repeat for <u>each</u> of the required properties listed in the BIBB definition, except for those properties which are commandable.	
	Repeat the test for a variety of values that cover the range of values	
	required by the "Minimum Writable Value Ranges" table in the DS-M-	
	A BIBB definition.	
Testing Hints		
135.1-2013 - 8.22.5 - Accep	135.1-2013 - 8.22.5 - Accepting Input and Commanding/Relinquishing Properties	
Test Conditionality	Must be executed.	
<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .	
<b>Testing Hints</b>		

#### 4.35.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties of Access Control objects.

klist
-------

<b>Test Conditionality</b>	Must be executed.
<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.
<b>Testing Hints</b>	

# 4.35.3 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	Verify Checklist		
	Test Conditionality Must be executed.		
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	<b>Testing Hints</b>		

#### 4.35.2 Supports DM-OCD-A

The IUT shall support DM-OCD-A in order to create and delete Access Control objects.

Verif	y Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DM-OCD-A, and that all object
		types required by DS-ACUC-A are claimed within DM-OCD-A.
	<b>Testing Hints</b>	

# 4.37 Data Sharing - Access Control Site Configuration - A

Devices claiming support for Data Sharing - Access Control Site Configuration - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control Site Configuration - A]

Data	Data Sharing - Access Control Site Configuration - A		
	R <sup>∔</sup>	Base Requirements	
	R	Supports DS-RP-A	
	R	Supports DS-WP-A	
	R	Supports DM-OCD-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.37 Data Sharing - Access Control Site Configuration - A]

#### 4.37 Data Sharing - Access Control Site Configuration - A

#### 4.37.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-2013 - 8.18.3 - Reading and Presenting Properties		
Test Conditionality	Must be executed.	
Test Directives	Repeat the test for <u>each</u> of the standard object types and associated	
	properties specified by DS-ACSC-A.	
Testing Hints		
135.1-2013 - 8.22.4 - Acceptin	ng Input and Modifying Properties	
Test Conditionality	Must be executed.	
Test Directives	Repeat the test for <u>each</u> of the required object types listed in the BIBB	
	definition.	
	Repeat for each of the required properties listed in the BIBB definition,	
	except for those properties which are commandable.	
	Repeat the test for a variety of values that cover the range of values	
	required by the "Minimum Writable Value Ranges" table in the DS-M-	
	A BIBB definition.	
Testing Hints		
135.1-2013 - 8.22.5 - Accepting Input and Commanding/Relinquishing Properties		
Test Conditionality	Must be executed.	
<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .	
<b>Testing Hints</b>		

## 4.37.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties of Access Control objects.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	Test Directives	Verify that the IUT claims support for DS-RP-A.	
	<b>Testing Hints</b>		

# 4.37.3 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	Verify Checklist		
	<b>Test Conditionality</b>	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	<b>Testing Hints</b>		

# 4.37.2 Supports DM-OCD-A

The IUT shall support DM-OCD-A in order to create and delete Access Control objects.

Verify Checklist		
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DM-OCD-A, and that all object types required by DS-ACSC-A are claimed within DM-OCD-A.
	<b>Testing Hints</b>	

# 4.40 Data Sharing - Access Control Access Door - A

Devices claiming support for Data Sharing - Access Control Access Door - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control Access Door - A]

Data	Data Sharing - Access Control Access Door - A		
	R <sup>‡</sup>	Base Requirements	
	R	Supports DS-RP-A	
	R	Supports DS-WP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.40 Data Sharing - Access Control Access Door - A]

#### 4.40 Data Sharing - Access Control Access Door - A

#### 4.40.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-2013 - 8.18.3 - Reading and Presenting Properties	
Test Conditionality	Must be executed.
<b>Test Directives</b>	Repeat the test for each of the standard object types and associated
	properties specified by DS-ACAD-A.
Testing Hints	
135.1-2013 - 8.22.4 - Acceptin	ng Input and Modifying Properties
Test Conditionality	Must be executed.
Test Directives	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.  Repeat for <u>each</u> of the required properties listed in the BIBB definition, except for those properties which are commandable.  Repeat the test for a variety of values that cover the range of values required by the "Minimum Writable Value Ranges" table in the DS-M-A BIBB definition.
Testing Hints	
135.1-2013 - 8.22.5 - Accepting Input and Commanding/Relinquishing Properties	
Test Conditionality	Must be executed.
<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .
<b>Testing Hints</b>	

#### 4.40.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties of Access Door objects.

Verif	Verify Checklist	
	<b>Test Conditionality</b>	Must be executed.

<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.
<b>Testing Hints</b>	

# 4.40.3 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update Access Door properties modified by the user.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	<b>Testing Hints</b>		

# 4.41 Data Sharing - Access Control Credential Data Input - A

Devices claiming support for Data Sharing - Access Control Credential Data Input - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Access Control Credential Data Input - A]

Data	Data Sharing - Access Control Credential Data Input - A		
	R⁴	Base Requirements	
	R	Supports DS-RP-A	
	R	Supports DS-WP-A	
R Supports DS-COV-A			
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.41 Data Sharing - Access Control Credential Data Input - A]

#### 4.41 Data Sharing - Access Control Credential Data Input - A

#### 4.41.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	135.1-2013 - 8.18.3 - Reading and Presenting Properties		
	<b>Test Conditionality</b>	Must be executed.	
	<b>Test Directives</b>	Repeat the test for each of the standard object types and associated	
		properties specified by DS-ACCDI-A.	
	<b>Testing Hints</b>		
135.1	-2013 - 8.22.4 - Acceptin	g Input and Modifying Properties	
	<b>Test Conditionality</b>	Must be executed.	
	<b>Test Directives</b>	Repeat the test for <u>each</u> of the required object types listed in the BIBB	
		definition.	
		Repeat for <u>each</u> of the required properties listed in the BIBB definition,	
		except for those properties which are commandable.	
		Repeat the test for a variety of values that cover the range of values	
		required by the "Minimum Writable Value Ranges" table in the DS-M-	
		A BIBB definition.	
	<b>Testing Hints</b>		
135.1-2013 - 8.22.5 - Accepting		g Input and Commanding/Relinquishing Properties	
	<b>Test Conditionality</b>	Must be executed.	
	<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .	
	<b>Testing Hints</b>		

## 4.41.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties of Credential Data Input objects.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.	
	<b>Testing Hints</b>		

# 4.41.3 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update Credential Data Input properties modified by the user.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	<b>Testing Hints</b>		

# 4.41.4 Supports DS-COV-A

The IUT shall support DS-COV-A in order to receives COV notifications for Credential Data Input objects.

Verif	rify Checklist	
	Test Conditionality	Must be executed.
	Test Directives	Verify that the IUT claims support for DS-COV-A, and that Credential
		Data Input is claimed within DM-COV-A.
	<b>Testing Hints</b>	

# 4.43 Data Sharing - Lighting Output - A

Devices claiming support for Data Sharing - Lighting Output - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Lighting Output - A]

Data	Data Sharing - Lighting Output - A		
	R⁴	Base Requirements	
	R	Supports DS-WP-A	
	<sup>4</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.43 Data Sharing - Lighting Output - A]

#### 4.43 Data Sharing - Lighting Output - A

#### 4.43.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	135.1-2013 - 8.22.1 - Writing Non-Array Properties		
	<b>Test Conditionality</b>	Must be executed if the IUT does not support DS-ALO-A.	
	<b>Test Directives</b>	Repeat the test for each of the object types listed in the BIBB, writing to the Present Value property.	
	<b>Testing Hints</b>		

#### 4.43.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to control objects.

Verif	Verify Checklist	
	<b>Test Conditionality</b>	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.
	<b>Testing Hints</b>	

# 4.44 Data Sharing - Lighting Output Status - A

Devices claiming support for Data Sharing - Lighting Output Status - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Lighting Output Status - A]

Dat	Data Sharing - Lighting Output Status - A		
	$R^{1}$	Base Requirements	
	R	Supports DS-RP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.44 Data Sharing - Lighting Output Status - A]

#### 4.44 Data Sharing - Lighting Output Status - A

#### 4.44.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	135.1-2013 - 8.18.1 - Reading Non-Array Properties		
	Test Conditionality		
	<b>Test Directives</b>	Repeat the test for each of the object types listed in the BIBB, reading the Present_Value and Egress_Active properties from the objects types as required by the BIBB.	
	<b>Testing Hints</b>		

#### 4.44.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to retrieve property values from lighting objects.

Verify Checklist		
	<b>Test Conditionality</b>	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A, and claims the ability to
		read non-array properties, Enumerated, Unsigned, and REAL properties.
	<b>Testing Hints</b>	

# 4.45 Data Sharing - Advanced Lighting Output - A

Devices claiming support for Data Sharing - Advanced Lighting Output - A must comply with the following section.

#### **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Advanced Lighting Output - A]

Data Sharing - Advanced Lighting Output - A			
	$R^{1}$	Base Requirements	
	R	Supports DS-WP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

#### **Test Plan Changes**

[In BTL Test Plan, replace section 4.45 Data Sharing - Advanced Lighting Output - A]

#### 4.45 Data Sharing - Advanced Lighting Output - A

#### 4.45.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-2013 - 8.22.1 - Writing Non-Array Properties		
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Repeat the test for each property of each of the object types listed in the
		BIBB, except those that are required to be read-only by the standard.
	<b>Testing Hints</b>	

#### 4.45.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to control objects.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	Test Directives	Verify that the IUT claims support for DS-WP-A.	
	<b>Testing Hints</b>		

# 4.48 Data Sharing - Lighting Output Management - A

Devices claiming support for Data Sharing - Lighting Output Management - A must comply with the following section.

# **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Lighting Output Management - A]

Data	Data Sharing - Lighting Output Management - A		
	R⁴	Base Requirements	
	R	Supports DM-OCD-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 4.48 Data Sharing - Lighting Output Management - A]

# 4.48 Data Sharing - Lighting Output Management - A

# 4.48.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB. There are no base requirements tests for this section.

# 4.48.2 Supports DM-OCD-A

The IUT shall support DM-OCD-A in order to create and delete Access Control objects.

Verif	rify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DM-OCD-A, and that all object	
		types required by DS-LOM-A are claimed within DM-OCD-A.	
	<b>Testing Hints</b>		

# 4.49 Data Sharing - Lighting View - A

Devices claiming support for Data Sharing - Lighting View - A must comply with the following section.

# **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Lighting View - A]

Dat	Data Sharing - Lighting View - A		
	R <sup>‡</sup>	Base Requirements	
	R	Supports DS-RP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 4.49 Data Sharing - Lighting View - A]

# 4.49 Data Sharing - Lighting View - A

# 4.49.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-2013 - 8.18.3 - Reading and Presenting Properties		
<b>Test Conditionality</b> Must be executed if the IUT does not support DS-LAV-A.		
<b>Test Directives</b>	Repeat the test for <u>each</u> of the standard object types and associated properties specified by DS-LV-A.	
<b>Testing Hints</b>		

# 4.49.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verify Checklist		
	Test Conditionality	Must be executed.
	Test Directives	Verify that the IUT claims support for DS-RP-A.
	Testing Hints	

# 4.50 Data Sharing - Lighting Advanced View - A

Devices claiming support for Data Sharing - Lighting Advanced View - A must comply with the following section.

# **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Lighting Advanced View - A]

Dat	Data Sharing - Lighting Advanced View - A		
	R <sup>4</sup> Base Requirements		
	R	Supports DS-RP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

## **Test Plan Changes**

[In BTL Test Plan, replace section 4.50 Data Sharing - Lighting Advanced View - A]

# 4.50 Data Sharing - Lighting Advanced View - A

## 4.50.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	35.1-2013 - 8.18.3 - Reading and Presenting Properties		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Repeat the test for <u>all</u> standard objects and properties identified in DS-LAV-A.	
		For properties that contain a CHOICE construct, the IUT shall be capable of reading and presenting each of the forms of the datatype as defined in the IUT's claimed protocol revision.  Full accuracy presentation is not required throughout the IUT, but there should be at least one place provided by the IUT that allows the presentation of each property to be presented in such a way that the presentation requirements of DS-LAV-A are met.	
	<b>Testing Hints</b>		

# 4.50.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verif	fy Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.	
	<b>Testing Hints</b>		

# 4.51 Data Sharing - Lighting Modify - A

Devices claiming support for Data Sharing - Lighting Modify - A must comply with the following section.

# **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Lighting Modify - A]

Dat	Data Sharing - Lighting Modify - A		
	R <sup>+</sup>	Base Requirements	
	R	Supports DS-WP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 4.51 Data Sharing - Lighting Modify - A]

# 4.51 Data Sharing - Lighting Modify - A

# 4.51.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	1-2013 - 8.22.4 - Accepting Input and Modifying Properties		
	Test Conditionality	Must be executed if the IUT does not support DS-LAM-A.	
	<b>Test Directives</b>	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.	
		Repeat for <u>each</u> of the required properties listed in the BIBB definition, except for those properties which are commandable.	
		Repeat the test for a variety of values that cover the range of values	
		required by the "Minimum Writable Value Ranges" table in the DS-M-	
		A BIBB definition.	
	<b>Testing Hints</b>		
135.1	-2013 - 8.22.5 - Acceptin	g Input and Commanding/Relinquishing Properties	
	Test Conditionality	Must be executed if the IUT does not support DS-LAM-A.	
	<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .	
	<b>Testing Hints</b>		

# 4.51.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verify Checklist		
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.
	Testing Hints	

# 4.52 Data Sharing - Lighting Advanced Modify - A

Devices claiming support for Data Sharing - Lighting Advanced Modify - A must comply with the following section.

# **Checklist Changes**

[In BTL Checklist, replace section Data Sharing - Lighting Advanced Modify - A]

Dat	Data Sharing - Lighting Advanced Modify - A		
	R <sup>1</sup>	Base Requirements	
	R	Supports DS-WP-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

## **Test Plan Changes**

[In BTL Test Plan, replace section 4.52 Data Sharing - Lighting Advanced Modify - A]

# 4.52 Data Sharing - Lighting Advanced Modify - A

## 4.52.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	35.1-2013 - 8.22.4 - Accepting Input and Modifying Properties		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Repeat the test for <u>each</u> of the required object types listed in the BIBB definition.	
		Repeat for <u>each</u> of the required properties listed in the BIBB definition, except for those properties which are commandable.	
		Repeat the test for a variety of values that cover the range of values	
		required by the "Minimum Writable Value Ranges" table in the DS-M-A BIBB definition.	
	<b>Testing Hints</b>		
135.1	-2013 - 8.22.5 - Acceptin	g Input and Commanding/Relinquishing Properties	
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	This test should be executed at priority 8 only, i.e. $PR_1 = 8$ .	
	<b>Testing Hints</b>		

# 4.52.2 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verify	Verify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	Testing Hints		

# 5.27 Alarm and Event Management - Life Safety View Notifications - A

Devices claiming support for Alarm and Event Management - Life Safety View Notification - A must comply with the following section.

## **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Life Safety View Notifications - A]

Alaı	Alarm and Event Management - Life Safety View Notifications - A		
	R <sup>4</sup> Base Requirements		
	R	Supports AE-N-A	
	R Supports AE-LS-A		
	<sup>+</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 5.27 Alarm and Event Management - Life Safety View Notifications - A]

# 5.27 Alarm and Event Management - Life Safety View Notifications - A

# 5.27.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

BTL -	BTL - 9.4.5 - ConfirmedEventNotification Simple Presentation	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Repeat the test for CHANGE_OF_LIFE_SAFETY, and each of the
		transitions defined for that event type.
		Repeat the test for FAULT_LIFE_SAFETY.
		Execute at least once with a Message_Text 32 or more characters in
		length.
	<b>Testing Hints</b>	
135.1	-2013 - 9.5.1 - Unconfirr	nedEventNotification Simple Presentation
	<b>Test Conditionality</b>	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for CHANGE_OF_LIFE_SAFETY, and each of the
	_	transitions defined for that event type.
		Repeat the test for FAULT_LIFE_SAFETY.
		Execute at least once with a Message_Text 32 or more characters in
		length.

# 5.27.2 Supports AE-N-A

The IUT shall support AE-N-A in order to receive and display event notifications.

Ver	Verify Checklist		
	<b>Test Conditionality</b>	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for AE-N-A.	

<b>Testing Hints</b>	

# 5.27.3 Supports AE-LS-A

The IUT shall support AE-LS-A in order to silence / unsilence life safety objects.

Verif	rify Checklist		
	Test Conditionality	Must be executed.	
	Test Directives	Verify that the IUT claims support for AE-LS-A.	
	<b>Testing Hints</b>		

# **5.28** Alarm and Event Management - Life Safety Advanced View Notifications - A

Devices claiming support for Alarm and Event Management - Life Safety Advanced View Notifications - A must comply with the following section.

## **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Life Safety Advanced View Notifications - A]

Ala	Alarm and Event Management - Life Safety Advanced View Notifications - A		
	R <sup>+</sup> Base Requirements		
	R	Supports AE-AVN-A	
	R Supports AE-LS-A		
	<sup>+</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 5.28 Alarm and Event Management - Life Safety Advanced View Notifications - A]

## 5.28 Alarm and Event Management - Life Safety Advanced View Notifications - A

## 5.28.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

BTL	- 9.4.6 - ConfirmedEven	tNotification Full Presentation
	Test Conditionality	Must be executed.
	Test Directives	Repeat the test for CHANGE_OF_LIFE_SAFETY, and each of the transitions defined for that event type.  Repeat the test for FAULT_LIFE_SAFETY.  Execute at least once with a Message_Text 256 or more characters in length.
	<b>Testing Hints</b>	
135.1	-2013 - 9.5.2 - Unconfiri	nedEventNotification Full Presentation
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for CHANGE_OF_LIFE_SAFETY, and each of the transitions defined for that event type.  Repeat the test for FAULT_LIFE_SAFETY.  Execute at least once with a Message_Text 256 or more characters in length.

# 5.28.2 Supports AE-AVN-A

The IUT shall support AE-AVN-A in order to receive and display standard event notifications for most standard object types.

Verif	erify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for AE-AVN-A.	
	<b>Testing Hints</b>		

# 5.28.3 Supports AE-LS-A

The IUT shall support AE-LS-A in order to silence / unsilence life safety objects.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for AE-LS-A.	
	<b>Testing Hints</b>		

# 5.29 Alarm and Event Management - Life Safety View Modify - A

Devices claiming support for Alarm and Event Management - Life Safety View Modify - A must comply with the following section.

# **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Life Safety View Modify - A]

Ala	Alarm and Event Management - Life Safety View Modify - A		
	R <sup>‡</sup>	Base Requirements	
	R	Supports DS-RP-A	
	R	Supports DS-WP-A	
	R Supports AE-VM-A		
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 5.29 Alarm and Event Management - Life Safety View Modify - A]

# 5.29 Alarm and Event Management - Life Safety View Modify - A

# **5.29.1 Base Requirements**

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-2013	- 8.18.3 - Reading	and Presenting Properties
Test	Conditionality	Must be executed if AE-LSAVM-A is not supported.
Test	Directives	Repeat the test for each standard object capable of generating CHANGE_OF_LIFE_SAFETY events, reading and displaying the
		pAlarmValues and pLifeSafetyAlarmValues properties.
		Repeat the test for each standard object capable of using the
		FAULT_LIFE_SAFETY algorithm, reading and displaying the
		pFaultValues property.
Testi	ing Hints	
135.1-2013	- 8.22.4 - Acceptin	g Input and Modifying Properties
Test	Conditionality	Must be executed if AE-LSAVM-A is not supported.
Test	Directives	Repeat the test for each standard object capable of generating
		CHANGE_OF_LIFE_SAFETY events, reading and displaying the
		pAlarmValues and pLifeSafetyAlarmValues properties.
		Repeat the test for each standard object capable of using the
		FAULT_LIFE_SAFETY algorithm, reading and displaying the
		pFaultValues property.
Test	ing Hints	

# 5.29.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verify Checklist	
Test Conditionality	Must be executed.

<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.
<b>Testing Hints</b>	

# 5.29.3 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.	
	<b>Testing Hints</b>		

# 5.29.4 Supports AE-VM-A

The IUT shall support AE-VM-A in order to facilitate configuration of alarm parameters by the user.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for AE-VM-A.
	<b>Testing Hints</b>	

# 5.30 Alarm and Event Management - Life Safety Advanced View Modify - A

Devices claiming support for Alarm and Event Management - Life Safety Advanced Modify - A must comply with the following section.

## **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Life Safety Advanced View Modify - A]

Alaı	Alarm and Event Management - Life Safety Advanced View Modify - A		
	R <sup>+</sup>	Base Requirements	
	R	Supports DS-RP-A	
	R	Supports DS-WP-A	
	R	Supports DM-OCD-A	
	R Supports AE-AVM-A		
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 5.30 Alarm and Event Management - Life Safety Advanced View Modify - A]

# 5.30 Alarm and Event Management - Life Safety Advanced View Modify - A

## **5.30.1 Base Requirements**

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	5.1-2013 - 8.18.3 - Reading and Presenting Properties	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for each standard event generating object type which can
		generate CHANGE_OF_LIFE_SAFETY event notifications, or use the
		FAULT_LIFE_SAFETY algorithm.
135.1	-2013 - 8.22.4 - Acceptin	g Input and Modifying Properties
	<b>Test Conditionality</b>	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for each standard event generating object type which can
		generate CHANGE_OF_LIFE_SAFETY event notifications, or use the
		FAULT_LIFE_SAFETY algorithm.

# 5.30.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.
	<b>Testing Hints</b>	

# 5.30.3 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.
	<b>Testing Hints</b>	

# 5.30.4 Supports DM-OCD-A

The IUT shall support DM-OCD-A in order to facilitate creation and deletion of life safety objects.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DM-OCD-A and that all object
		types required by DS-LSAVM-A are claimed within DM-OCD-A.
	<b>Testing Hints</b>	

# 5.30.5 Supports AE-AVM-A

The IUT shall support AE-AVM-A in order to facilitate configuration of alarm parameters by the user.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for AE-AVM-A.
	<b>Testing Hints</b>	

# 5.31 Alarm and Event Management - Access Control - A

Devices claiming support for Alarm and Event Management - Access Control - A must comply with the following section.

# **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Access Control - A]

Alarm and Ev	Alarm and Event Management - Access Control - A		
R	Base Requirements		
R	Executes ConfirmedEventNotifications		
R	Executes UnconfirmedEventNotifications		
R	Processes intrinsically generated notifications		
R	Processes algorithmically generated notifications		
R	Processes event notifications with timestamps of the BACnetDateTime form		
R	Processes event notifications with timestamps of the Time form		
R	Processes event notifications with timestamps of the Sequence Number form		
R	Supports AE-ACK-A		

# **Test Plan Changes**

[In BTL Test Plan, replace section 5.31 Alarm and Event Management - Access Control - A]

# 5.31 Alarm and Event Management - Access Control - A

## **5.31.1 Base Requirements**

Base requirements must be met by any IUT claiming conformance to this BIBB.

BTL .	BTL - 9.4.X1 - Unsupported Message Text Character Set ConfirmedEventNotification Test		
	Test Conditionality	If the IUT supports all character sets, this test shall be skipped.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL .	BTL - 9.5.X1 - Unsupported Message Text Character Set UnconfirmedEventNotification Test		
	Test Conditionality	If the IUT supports all character sets, this test shall be skipped.	
	Test Directives		
	<b>Testing Hints</b>		

### 5.31.2 Executes ConfirmedEventNotifications

The IUT is capable of executing ConfirmedEventNotifications with an Event Type of ACCESS\_EVENT. This functionality will be covered by the testing of the individual algorithms.

No S	No Specific Test		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT's EPICS claims that it supports the	
		ConfirmedEventNotification service.	
	<b>Testing Hints</b>		

### 5.31.3 Executes UnconfirmedEventNotifications

The IUT is capable of executing UnconfirmedEventNotifications with an Event Type of ACCESS\_EVENT. There are currently no tests defined for this functional item.

No S	o Specific Test		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Verify that the IUT's EPICS claims that it supports the	
		UnconfirmedEventNotification service.	
	<b>Testing Hints</b>		

# **5.31.4 Processes Intrinsically Generated Notifications**

The IUT is capable of executing ConfirmedEventNotifications with an Event Type of ACCESS\_EVENT that reference an object type other than Event Enrollment.

Parar 135.1- Parar	135.1-2013 - 9.4.1 - ConfirmedEventNotification Using the Time Form of the 'Timestamp' Parameter and Conveying a Text Message, 135.1-2013 - 9.4.2 - ConfirmedEventNotification Using the DateTime Form of the 'Timestamp' Parameter and no Text Message, or		
	135.1-2013 - 9.4.3 - ConfirmedEventNotification Using the Sequence Number Form of the		
'Time	'Timestamp' Parameter and no Text Message		
	Test Conditionality	At least one of the tests must be executed with the Event Object	
		Identifier referencing a BACnet object other than an Event Enrollment	
		object.	
	<b>Test Directives</b>	Execute using an event type of ACCESS_EVENT.	
	<b>Testing Hints</b>		

# 5.31.5 Processes Algorithmically Generated Notifications

The IUT is capable of executing ConfirmedEventNotifications with an Event Type of ACCESS\_EVENT that reference an Event Enrollment object.

135.1-2013 - 9.4.1 - ConfirmedEventNotification Using the Time Form of the 'Timestamp' Parameter and Conveying a Text Message, 135.1-2013 - 9.4.2 - ConfirmedEventNotification Using the DateTime Form of the 'Timestamp' Parameter and no Text Message, or 135.1-2013 - 9.4.3 - ConfirmedEventNotification Using the Sequence Number Form of the		
	Timestamp' Parameter and no Text Message  Test Conditionality  At least one of the tests must be executed with the Event Object	
		Identifier referencing an Event Enrollment object.
	<b>Test Directives</b>	Execute using an event type of ACCESS EVENT.
	<b>Testing Hints</b>	

# 5.31.6 Processes Event Notifications with Timestamps of the BACnetDateTime Form

The IUT is capable of executing ConfirmedEventNotifications that contain a timestamp of the BACnetDateTime form.

135.1	135.1-2013 - 9.4.2 - ConfirmedEventNotification Using the DateTime Form of the 'Timestamp'		
Para	Parameter and no Text Message		
	Test Conditionality	Must be executed.	
	Test Directives	Execute using an event type of ACCESS_EVENT.	
	<b>Testing Hints</b>		

# 5.31.7 Processes Event Notifications with Timestamps of the Time Form

The IUT is capable of executing ConfirmedEventNotifications that contain a timestamp of the Time form.

135.1	135.1-2013 - 9.4.1 - ConfirmedEventNotification Using the Time Form of the 'Timestamp'		
Para	Parameter and Conveying a Text Message		
	Test Conditionality	Must be executed.	
	<b>Test Directives</b>	Execute using an event type of ACCESS_EVENT.	
	<b>Testing Hints</b>		

# **5.31.8** Processes Event Notifications with Timestamps of the Sequence Number Form

The IUT is capable of executing ConfirmedEventNotifications that contain a timestamp of the Sequence Number form.

135.1-2013 - 9.4.3 - ConfirmedEventNotification Using the Sequence Number Form of the 'Timestamp' Parameter and no Text Message		
Test Conditionality	Must be executed.	
<b>Test Directives</b>	Execute using an event type of ACCESS EVENT.	
<b>Testing Hints</b>		

# 5.31.9 Supports AE-ACK-A

The IUT must support AE-ACK-A if it claims support for AE-AC-A.

Veri	fy Checklist	
	Test Conditionality	Must be executed.
	Test Directives	Verify that the IUT claims support for AE-ACK-A in the
		Checklist.
	<b>Testing Hints</b>	
BTI	8.1 - ACKNOWLEDGEALARM S	SERVICE INITIATION TESTS
	TEST CONDITIONALITY	Must be executed.
	Test Directives	Execute using an event type of ACCESS_EVENT.
		Execute once to acknowledge a
		ConfirmedEventNotification, and again to acknowledge an
		UnconfirmedEventNotification.
	TESTING HINTS	

# **5.33** Alarm and Event Management - Access Controls Advanced View Notifications - A

Devices claiming support for Alarm and Event Management - Access Control Advanced View Notifications - A must comply with the following section.

## **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Access Control Advanced View Notifications - A]

Alaı	Alarm and Event Management - Access Control Advanced View Notifications - A		
	R <sup>4</sup> Base Requirements		
	R	Supports AE-AVN-A	
	R	Supports AE-AC-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 5.33 Alarm and Event Management - Access Controls Advanced View Notifications - A]

## 5.33 Alarm and Event Management - Access Controls Advanced View Notifications - A

# **5.33.1 Base Requirements**

Base requirements must be met by any IUT claiming conformance to this BIBB.

BTL	BTL - 9.4.6 - ConfirmedEventNotification Full Presentation	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Repeat the test for ACCESS_EVENT, and each of the transitions defined for that event type.
		Execute at least once with a Message_Text 256 or more characters in length.
	<b>Testing Hints</b>	
135.1	-2013 - 9.5.2 - Unconfiri	medEventNotification Full Presentation
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for ACCESS_EVENT, and each of the transitions defined for that event type.  Execute at least once with a Message_Text 256 or more characters in length.

# 5.33.2 Supports AE-AVN-A

The IUT must support AE-AVN-A in order to receive and display standard event notifications for most standard object types.

Verif	Verify Checklist		
	Test Conditionality	Must be executed.	
	Test Directives	Verify that the IUT claims support for AE-AVN-A in the Checklist.	

<b>Testing Hints</b>	
Testing Illies	

# 5.33.3 Supports AE-AC-A

The IUT must support AE-AC-A if it claims support for AE-ACAVN-A.

Verif	y Checklist	
	Test Conditionality	Must be executed.
	Test Directives	Verify that the IUT claims support for AE-AC-A in the Checklist.
	<b>Testing Hints</b>	

# 5.34 Alarm and Event Management - Access Control View Modify - A

Devices claiming support for Alarm and Event Management - Access Control View Modify - A must comply with the following section.

## **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Access Control View Modify - A]

Ala	Alarm and Event Management - Access Control View Modify - A	
	R <sup>1</sup>	Base Requirements
	R	Supports AE-VM-A
	<sup>1</sup> Contact BTL for interim tests for this BIBB.	

# **Test Plan Changes**

[In BTL Test Plan, replace section 5.34 Alarm and Event Management - Access Control View Modify - A]

# 5.34 Alarm and Event Management - Access Control View Modify - A

# **5.34.1 Base Requirements**

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	135.1-2013 - 8.18.3 - Reading and Presenting Properties	
	Test Conditionality	Must be executed if AE-ACAVM-A is not supported.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for each standard object capable of generating
		ACCESS_EVENT events, reading and displaying the pAccessEvents
		and pAccessEventTime properties.
135.1	-2013 - 8.22.4 - Acceptin	g Input and Modifying Properties
	Test Conditionality	Must be executed if AE-ACAVM-A is not supported.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for each standard object capable of generating
		ACCESS_EVENT events, reading and displaying the pAccessEvents
		and pAccessEventTime properties.

# 5.34.2 Supports AE-VM-A

The IUT shall support AE-VM-A in order to facilitate configuration of alarm parameters by the user.

Verify Checklist		
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for AE-VM-A.
	Testing Hints	

# **5.35** Alarm and Event Management - Access Control Advanced View Modify - A

Devices claiming support for Alarm and Event Management - Access Control Advanced View Modify - A must comply with the following section.

## **Checklist Changes**

[In BTL Checklist, replace section Alarm and Event Management - Access Control Advanced View Modify - A]

Alaı	Alarm and Event Management - Access Control Advanced View Modify - A		
	R <sup>‡</sup>	Base Requirements	
	R	Supports DS-RP-A	
	R	Supports DS-WP-A	
	R	Supports D-OCD-A	
	R	Supports AE-AVM-A	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

## **Test Plan Changes**

[In BTL Test Plan, replace section 5.35 Alarm and Event Management - Access Control Advanced View Modify - A]

# 5.35 Alarm and Event Management - Access Control Advanced View Modify - A

# **5.35.1 Base Requirements**

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1	135.1-2013 - 8.18.3 - Reading and Presenting Properties	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for each standard event generating object type which can generate ACCESS_EVENT event notifications.
135.1	-2013 - 8.22.4 - Acceptii	ng Input and Modifying Properties
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	Repeat the test for each standard event generating object type which can generate ACCESS_EVENT event notifications.

# 5.35.2 Supports DS-RP-A

The IUT shall support DS-RP-A in order to read properties for presentation.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-RP-A.
	<b>Testing Hints</b>	

# 5.35.3 Supports DS-WP-A

The IUT shall support DS-WP-A in order to update properties modified by the user.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for DS-WP-A.
	<b>Testing Hints</b>	

# 5.35.4 Supports DM-OCD-A

The IUT shall support DM-OCD-A in order to facilitate creation and deletion of life safety objects.

Verif	y Checklist	
	Test Conditionality	Must be executed.
	Test Directives	Verify that the IUT claims support for DM-OCD-A and that all object
		types required by DS-ACAVM-A are claimed within DM-OCD-A.
	<b>Testing Hints</b>	

# 5.35.5 Supports AE-AVM-A

The IUT shall support AE-AVM-A in order to facilitate configuration of alarm parameters by the user.

Verif	Verify Checklist	
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	Verify that the IUT claims support for AE-AVM-A.
	<b>Testing Hints</b>	

# 8.30 Device Management - Slave Proxy - B

Devices claiming support for Device Management - Slave Proxy - B must claim support for Protocol\_Revision 4 or higher and comply with the following section.

Addendum 135-2001a added MS/TP slave proxy functionality. This document makes needed changes in the BTL Test Package to claim the associated BIBB DM-SP-B.

These changes are not contained in any SSPC proposal.

# **Checklist Changes**

[In BTL Checklist, replace Device Management - Slave Proxy - B section]

Device Management - Slave Proxy - B			
	$\mathbb{R}^1$	Base Requirements	
	0	Supports Automatic Slave Address Binding	
	<sup>1</sup> Contact BTL for interim tests for this BIBB.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 8.30 Device Management - Slave Proxy - B]

# 8.30 Device Management - Slave Proxy - B

## 8.30.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

135.1-2013 - 13.5.1 Manual Slave Binding Test		
Test Conditionality	Must be executed.	
<b>Test Directives</b>		
<b>Testing Hints</b>		
135.1-2013 - 13.5.3 Proxy T	135.1-2013 - 13.5.3 Proxy Test	
Test Conditionality	Must be executed.	
<b>Test Directives</b>		
<b>Testing Hints</b>		

# 8.30.2 Supports Automatic Slave Address Binding

The IUT support automatic slave address binding.

135.1-2013 - 13.5.2 Automatic Slave Discovery Test		
Test Conditiona	lity Must be executed.	
Test Directives		
<b>Testing Hints</b>		

# 9.4 BACnet/IP - Annex J - BBMD

The operation and manipulation of Broadcast Distribution Tables in devices claiming Protocol\_Revision 17 or higher is performed through operations on a Network Port object for each supported port.

# **Test Plan Changes**

[In BTL Test Plan, add test to end of Base Requirements for BACnet/IP - Annex J - BBMD]

## 9.4 BACnet/IP - Annex J - BBMD

# 9.4.1 Base Requirements

The IUT acts, or can be made to act, as a BBMD device.

These base requirements must be met by any IUT that claims to support the Annex J BACnet/IP BBMD functionality.

	• • •		
BTL	BTL – 14.3.X1 - Write-BDT service is required to return Write-BDT-NAK		
	<b>Test Conditionality</b>	Must be executed in all devices claiming Protocol_Revision >= 17.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 10.7 Network Management - BBMD Configuration - B

Addendum 135-2012*al* added the NM-BBMDC-B BIBB. This document makes needed changes in the BTL Test Package to claim NM-BBMDC-B.

These changes are not contained in any SSPC proposal.

## **Checklist Changes**

[In BTL Checklist, replace Network Management - BBMD Configuration - B section]

Support			
Net	work Mana	gement - BACnet Broadcast Management Device Configuration - B	
	R	Base Requirements	
	R	Supports Registration by Foreign Devices	
	BTL-C1	Executes Write-Broadcast-Distribution-Table	
	$C^2$	Supports configurable BBMD_Broadcast_Distribution_Table property	
<sup>1</sup> Th	<sup>1</sup> This option is required if the IUT claims Protocol_Revision 16 or lower.		
<sup>2</sup> Th	<sup>2</sup> This option is required if the IUT claims Protocol_Revision 17 or higher.		

# **Test Plan Changes**

[In BTL Test Plan, replace section 10.7 Network Management - BBMD Configuration - B]

# 10.7 Network Management - BBMD Configuration - B

These tests are designed for testing implementations of a BACnet Broadcast Management Device, including the execution of Network Layer and Application Layer commands to configure the BBMD.

# 10.7.1 Base Requirements

Base requirements must be met by any IUT claiming conformance to this BIBB.

BTL	BTL - 14.2.1.2 - Execute Forwarded-NPDU (Two-hop Distribution)		
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD	
		Functionality.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	BTL - 14.2.2.2 - Execute Original-Broadcast-NPDU (Two-hop Distribution)		
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD	
		Functionality.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
135.1	135.1-2013 - 14.2.3 - Execute Original-Unicast-NPDU		

	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD
		Functionality.
	<b>Test Directives</b>	•
	<b>Testing Hints</b>	
135.1	-2013 - 14.5.2.2 - Origi	nal-Broadcast-NPDU Which Shall Be Forwarded (Two-hop Distribution)
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD
		Functionality.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
BTL	- 14.7.1.2 - Broadcast I	Message from Directly Connected IP Subnet (Two-hop Distribution)
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD
		Functionality.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
BTL	- 14.7.2.2 - Broadcast I	Message Forwarded by a Peer BBMD (Two-hop Distribution)
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD Functionality.
	Test Directives	
	<b>Testing Hints</b>	
135.1	-2013 - 14.9.3 - Origina	al-Broadcast-NPDU
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD
		Functionality.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
_		

# 10.7.2 Supports Registration by Foreign Devices

While configured as a BBMD, the IUT supports, or can be made to support, registration by Foreign Devices and forwards as original BACnet/IP unicasts to each, any broadcasts it processes.

BTL -	14.6.X1 - Holds at lea	ast 5 Foreign Device Registrations
	Test Conditionality	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
BTL -	14.6.X2 - Negative Fo	oreign Device Registration when FD_Supported is FALSE
	<b>Test Conditionality</b>	Must be executed.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
135.1-	2013 - 14.6.1 - Execut	e Read-Foreign-Device-Table
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD Functionality.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
135.1-	2013 - 14.6.3.1 - Non-z	zero-Duration Foreign Device Table Timer Operations
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD Functionality.
	<b>Test Directives</b>	
	<b>Testing Hints</b>	
135.1-	2013 - 14.6.5 - Execut	e Delete-Foreign-Device-Table-Entry Which Should Be Rejected
	<b>Test Conditionality</b>	This test may be skipped if the IUT claims support for BACnet/IP - BBMD Functionality.
	<b>Test Directives</b>	·
	<b>Testing Hints</b>	

135.1	135.1-2013 - 14.6.6 - Execute Delete-Foreign-Device-Table-Entry		
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD	
		Functionality.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	BTL - 14.7.3.2 - Broadcast Message From a Foreign Device (Two-hop Distribution)		
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD	
		Functionality.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# 10.7.3 Executes Write-Broadcast-Distribution-Table

The IUT executes Write-Broadcast-Distribution-Table to update the configured peer BBMDs.

135.1	135.1-2013 - 14.3.1 - Execute Write-Broadcast-Distribution-Table (Table Growth)		
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD	
		Functionality.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
135.1	135.1-2013 - 14.3.2 - Execute Write-Broadcast-Distribution-Table (Table Shrinkage)		
	Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD	
		Functionality.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	BTL - 14.3.3 - Verify Broadcast Distribution Table Created from the Configuration Saved During the		
	Previous Session		
Previ	ious Session		
Previ	ious Session  Test Conditionality	This test may be skipped if the IUT claims support for BACnet/IP - BBMD	
Previ		This test may be skipped if the IUT claims support for BACnet/IP - BBMD Functionality.	
Previ			
Previ	Test Conditionality		
	Test Conditionality Test Directives Testing Hints		
	Test Conditionality Test Directives Testing Hints	Functionality.	
	Test Conditionality  Test Directives  Testing Hints  - 14.3.X2 - Broadcast-	Functionality.  Distribution-Table Holds at least 5 Entries	

# 10.7.4 Supports BBMD Broadcast Distribution Table property

The IUT supports the configurable BBMD\_Broadcast\_Distribution\_Table property in Network Port objects to configure peer BBMDs.

BTL	BTL - 14.3.X3 - BBMD_Broadcast_Distribution_Table Holds at Least 5 Entries		
	<b>Test Conditionality</b>	Must be executed.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		
BTL	BTL – 14.3.X1 - Write-BDT service is required to return Write-BDT-NAK		
	Test Conditionality	Must be executed in all devices claiming Protocol_Revision >= 17.	
	<b>Test Directives</b>		
	<b>Testing Hints</b>		

# **BTL Specified Tests Changes**

This section contains all of the new and changes tests required by the interim test BTL Checklist and BTL Test Plan changes.

[Network Port Object Tests]

[In BTL Specified Tests, add clause 7.3.2.X43 Network Port Object Tests]

#### 7.3.2.X43 Network Port Object Tests

#### 7.3.2.X43.1 Network Port ACTIVATE CHANGES test

Reason for Change: New test per Addendum 135-2012ai.

Purpose: This test verifies that after any of the Network Port properties are changed, the revised value is activated when executing a ReinitializeDevice ACTIVATE CHANGES service request.

Test Concept: Write any of the writable properties of a Network Port object and activate those changes by issuing a ReinitializeDevice – WARMSTART or ACTIVATE\_CHANGES service request. Then after the IUT has time to have finished its update, verify that the Network Port object properties contain the values that were written.

#### Test Steps:

- 1. WRITE (any writable Network Port property) = (a value different from current value)
- 2. VERIFY Changes\_Pending = TRUE
- 3. TRANSMIT ReinitializeDevice-Request

'Reinitialized State of Device' = WARMSTART | ACTIVATE\_CHANGES

'Password' = (any valid password)

- 4. RECEIVE BACnet-SimpleACK-PDU
- 5. CHECK (that the IUT has had time to have finished its update)
- 6. REPEAT X for each changed Network Port property)

VERIFY X =(the revised value to which it was changed)

7. VERIFY Changes Pending = FALSE

#### 7.3.2.X43.2 Network Port non-volatility properties test

Reason for Change: New test per Addendum 135-2012ai.

Purpose: This test verifies that after any of the Network Port properties is changed, and the revised value is activated, then the revised value with which it was configured is maintained through a power failure and device restart.

Test Concept: Write any of the writable properties of a Network Port object (multiple properties may be written), and activate those changes by issuing a ReinitializeDevice – WARMSTART or ACTIVATE\_CHANGES service request. Then after the IUT has time to have finished its update, restart the IUT device by temporarily removing power. When the device has resumed operation after that restart, verify that the Network Port object properties contain the values that were changed and activated.

#### Test Steps:

- 1. WRITE (X, any writable Network Port property) = (a value different from current value)
- 2. TRANSMIT ReinitializeDevice-Request

'Reinitialized State of Device' = WARMSTART | ACTIVATE\_CHANGES 'Password' = (any valid password)

- 3. RECEIVE BACnet-SimpleACK-PDU
- 4. WAIT for IUT to have finished its update
- 5. CHECK (that the IUT has had time to have finished its update)
- 6. VERIFY X =(the revised value to which it was changed)
- 7. MAKE (the IUT power cycle to reinitialize)
- 8. VERIFY X =(the revised value to which it was changed)

# 7.3.2.X43.3 Out\_Of\_Service, Status\_Flags, and Reliability test for an Object that does not contain Present Value

Purpose: This test verifies the interrelationship between the Out\_Of\_Service, Status\_Flags, and Reliability properties. If the PICS indicates that the Out\_Of\_Service property of the object under test is not writable, and if the value of the property cannot be changed by other means, then this test shall be omitted. This test applies to objects that do not contain Present\_Value.

Test Concept: Write to and verify the interrelationship between the Out\_Of\_Service, Status\_Flags, and Reliability properties of an object which does not contain Present\_Value.

Configuration Requirements: The selected object is configured such that its Reliability is NO\_FAULT\_DETECTED before execution of this test.

Test Steps:

```
1. IF (Out Of Service is writable) THEN
       WRITE Out Of Service = TRUE
       MAKE (Out_Of_Service = TRUE)
   VERIFY Out Of Service = TRUE
   VERIFY Status Flags = (?, FALSE, ?, TRUE)
   IF (Reliability is present and writable) THEN
       REPEAT X = (all values of the Reliability enumeration appropriate to the object type except
                       NO FAULT DETECTED) DO {
           WRITE Reliability = X
           VERIFY Reliability = X
           VERIFY Status Flags = (TRUE, TRUE,?, TRUE)
           WRITE Reliability = NO_FAULT_DETECTED
           VERIFY Reliability = NO FAULT DETECTED
           VERIFY Status_Flags = (? FALSE, ?, TRUE)
5. CHECK (all communication of the protocol modeled by the object, through that port is disabled)
   IF (Out_Of_Service is writable) THEN
       WRITE Out_Of_Service = FALSE
   ELSE
       MAKE (Out_Of_Service = FALSE)
   VERIFY Out_Of_Service = FALSE
```

[Elevator Group, Escalaror, and Lift Object Tests] [In BTL Specified Tests, add clause 7.3.2.X45]

VERIFY Status Flags = (?,?,?,FALSE)

#### 7.3.2.X45.1 Linking of Elevator Group Object Tests

### 7.3.2.X45.1.1 Machine\_Room\_ID property linking with the Positive\_Integer\_Value Object

Purpose: To verify that Machine\_Room\_ID property of Elevator Group reference the Positive\_Integer\_Value (PIV) object, whose Present\_Value property contains the identification number for the machine room that contains the group of Lifts or Escalators, represented by this object.

Test Concept: A machine room contains the Elevator Group which is having a group of Lifts or Escalators. This machine room is mapped to the Present\_Value property of Positive\_Integer\_Value Object which in turn is referenced to the Machine\_Room\_ID property of Elevator Group.

Configuration Requirements: The Machine room contains Elevator Group (EG1). OBJECT is any valid object type. X is any valid instance number in the range 0 to 4194302.

Test Steps:

```
    IF (Machine_Room_ID contains room identification number) THEN VERIFY (EG1), Machine_Room_ID = (PIV, X)
    ELSE
    VERIFY (EG1), Machine_Room_ID = (OBJECT, 4194303)
```

#### 7.3.2.X45.1.2 Linking of Lift Objects under Group\_Members property of the Elevator Group Object

Purpose: This test verifies that the Group\_Members property of the Elevator Group object contains the object identifier of the Lift object representing lifts contained within the group represented by this Elevator Group object.

Test Concept: Tester selects an Elevator Group and reads the Group\_Members property of the Elevator Group and verifies that all the Lifts that are configured under one group are present under the Group\_Members property of the Elevator Group object.

Configuration Requirements: Configure 2 Lifts (L1 and L2) under the Elevator Group (EG1).

Test Steps:

1. VERIFY (EG1), Group\_Members = (L1, L2)

#### 7.3.2.X45.1.3 Linking of Escalator Objects under Group\_Members property of the Elevator Group Object

Purpose: This test verifies that the Group\_Members property of the Elevator Group object contains the object identifier of the Escalator object representing the escalators contained within the group represented by this Elevator Group object.

Test Concept: Tester selects an Elevator Group and reads the Group\_Members property of the Elevator Group and verifies that all the Escalators that are configured under one group are present under the Group\_Members property of the Elevator Group object.

Configuration Requirements: Configure 2 Escalators (E1 and E2) under the Elevator Group (EG1).

Test Steps:

1. VERIFY (EG1), Group\_Members = (E1, E2)

#### 7.3.2.X45.1.4 Linking of Landing\_Call\_Control Property Test

Purpose: To verify that writing Landing\_Call\_Control property of Elevator Group assigns an active call to the Lift Object linked by pushing it to the Assigned\_Landing\_Calls property of the Lift object.

Test Concept: An Elevator Group is available, and it contains at least one Lift object. Landing\_Call\_Control property of the Elevator Group is written with a Floor number and direction or destination for the lift. Value written to Landing\_Call\_Control property is updated in the Landing\_Calls property of the Elevator Group which in turn updates the Assigned\_Landing\_Calls property of Lift. This test shall be skipped in the event of absence of Landing\_Call\_Control property. If any of the Landing\_Calls or Assigned\_Landing\_Calls property is not present, then the test steps for that specific property shall be skipped.

Configuration Requirements: The Lift (L1) should be present in the Group\_Members property of Elevator Group (EG1). Lowest universal floor number of the lift < A < Highest universal floor number of the lift. Lowest universal

floor number of the lift  $\leq$  X  $\leq$  Highest universal floor number of the lift. B = (UP | DOWN | UP\_AND\_DOWN) and C = (B | UP\_AND\_DOWN).

#### Test Steps:

- 1. WRITE (EG1), Landing\_Call\_Control = (Floor Number A, Direction B | Destination X)
- 2. VERIFY (EG1), Landing\_Call\_Control = (Floor Number A, Direction B | Destination X)
- 3. VERIFY (EG1), Landing\_Calls = (Floor Number A, Direction C | Destination X)
- 4. VERIFY (L1), Assigned\_Landing\_Calls = (Floor Number A, Direction C)

Notes to Tester: Landing\_Calls property may contain other entries from same lift or different lifts connected under same Elevator Group. If the Elevator Group contains more than 1 lift, value written to Landing\_Call\_Control may get assigned to any other lift, based on the lift algorithm.

[In BTL Specified Tests, add clause 7.3.2.X46.1]

7.3.2.X46.1 Escalator Object Tests

# 7.3.2.X46.1.1 Elevator\_Group property of Escalator Object linking with Group\_Members property of Elevator Group Object

Purpose: This test verifies that Elevator\_Group property of Escalator object shall have reference of Elevator Group object whose Group\_Members property contains a reference of Escalator object.

Test Concept: Escalator object falls under one specific Elevator Group object. The reference of Elevator Group object should be mentioned in Elevator\_Group property of Escalator object. If there is no such Elevator Group object, Elevator\_Group property shall contain an object instance of 4194303.

Configuration Requirements: The Escalator (E1), should be present under Elevator Group (EG1). OBJECT is any valid object type.

#### Test Steps:

- 1. VERIFY (E1), Elevator\_Group = (EG1)
- 2. VERIFY (EG1), Group Members =  $((E1), \ldots, En)$
- 3. IF (IUT does not contain reference of any Elevator Group Object) THEN VERIFY (E1), Elevator\_Group = (OBJECT, 4194303)

#### 7.3.2.X46.1.2 Energy\_Meter, Power\_Mode and Operation\_Direction Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Escalator object, it does not track the changes made for Energy\_Meter, Power\_Mode and Operation\_Direction property and it does not control the escalator operation from these properties.

Test Concept: When the Out\_Of\_Service is set to TRUE, writing Energy\_Meter, Power\_Mode and Operation\_Direction property shall not make escalator to update its energy value, power mode and operation direction. Also, while making escalator's energy, power mode and operation direction change from current status, it shall not get updated to Energy\_Meter, Power\_Mode and Operation\_Direction property of the Escalator object. Out\_Of\_Service property of the Escalator object is set to TRUE in the beginning of the test. If either of the Energy\_Meter or Power\_Mode properties are not present, then the test steps for that specific property shall be skipped.

Configuration Requirements: The Escalator Object supports Energy\_Meter and/or Power\_Mode properties.

Escalator Power\_Mode is TRUE and Operation\_Direction is STOPPED. Escalator is having energy meter value =

X. Tester shall select any value for energy meter Y; Y < 99999 or permitted by IUT. Tester shall select any Operation Direction supported by IUT while testing.

#### Test Steps:

```
IF (Out Of Service is writable) THEN
    WRITE Out_Of_Service = TRUE
ELSE
    MAKE (Out_Of_Service = TRUE)
VERIFY Out_Of_Service = TRUE
```

- VERIFY Status\_Flags = (?, ?, ?, TRUE)
- WRITE Energy Meter = Y
- VERIFY Energy Meter = Y
- 6. CHECK (the escalator's energy consumption is having value = X or value other than Y)
- 7. MAKE (the escalator's energy consumption value = Z)
- 8. VERIFY Energy Meter = Y
- 9. WRITE Power Mode = FALSE
- 10. VERIFY Power Mode = FALSE
- 11. CHECK (the escalator is still powered up independent of the value written)
- 12. MAKE (the escalator's power mode to be TRUE from FALSE)
- 13. VERIFY Power Mode = FALSE
- 14. WRITE Operation\_Direction = UP\_RATED\_SPEED
- 15. VERIFY Operation\_Direction = UP\_RATED\_SPEED
- 16. CHECK (the escalator remains stopped)
- 17. MAKE (the escalator's operation direction to be DOWN RATED SPEED)
- 18. VERIFY Operation\_Direction = UP\_RATED\_SPEED
- 19. IF (Out Of Service is writable) THEN

WRITE Out\_Of\_Service = FALSE

**ELSE** 

MAKE (Out Of Service = FALSE)

- 20. VERIFY Out Of Service = FALSE
- 21. VERIFY Status\_Flags = (?, ?, ?, FALSE)

#### 7.3.2.X46.1.3 Passenger\_Alarm and Fault\_Signals Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Escalator object, it does not track the changes made for Passenger\_Alarm and Fault\_Signals property and it does not control the escalator operation from these properties.

Test Concept: When the Out Of Service is set to TRUE, writing Passenger Alarm and Fault Signals property shall not make escalator to update its alarm and fault status. Also, while making escalator's fault and alarm status change from current value, it shall not get updated to Passenger\_Alarm and Fault\_Signals property of the Escalator object. Out\_Of\_Service property of the Escalator object is set to TRUE in the beginning of the test. If Fault\_Signals property is not present, then the respective test steps shall be skipped.

Configuration Requirements: Escalator has no alarm or fault at the start of test. Tester shall select any value for Fault Signals property testing that is supported by IUT.

#### Test Steps:

```
1. IF (Out_Of_Service is writable) THEN
           WRITE Out_Of_Service = TRUE
   ELSE
           MAKE (Out_Of_Service = TRUE)
```

VERIFY Out\_Of\_Service = TRUE

- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)
- 4. WRITE Passenger Alarm = TRUE
- 5. VERIFY Passenger\_Alarm = TRUE
- 6. CHECK (the escalator's alarm is not triggered)
- 7. MAKE (the escalator in NORMAL state)
- 8. VERIFY Passenger Alarm = TRUE
- 9. WRITE Fault\_Signals = OVERSPEED\_FAULT
- 10. VERIFY Fault\_Signals = OVERSPEED\_FAULT
- 11. CHECK (the escalator does not have any fault into it)
- 12. MAKE (the escalator to have SAFETY\_DEVICE\_FAULT fault)
- 13. VERIFY Fault\_Signals = OVERSPEED\_FAULT
- 14. IF (Out Of Service is writable) THEN

WRITE Out Of Service = FALSE

ELSE

MAKE (Out Of Service = FALSE)

- 15. VERIFY Out\_Of\_Service = FALSE
- 16. VERIFY Status\_Flags = (?, ?, ?, FALSE)

#### 7.3.2.X46.1.4 Escalator\_Mode Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Escalator object, it does not track the changes made for Escalator\_Mode property and also it does not control the escalator operation from this property.

Test Concept: When the Out\_Of\_Service is set to TRUE, writing Escalator\_Mode property shall not make escalator to update its mode. Also, while making escalator's mode to change from current value, it shall not get updated to Escalator\_Mode property of the Escalator object. Out\_Of\_Service property of the Escalator object is set to TRUE in the beginning of the test. If this property is not present, then this test shall be skipped.

Configuration Requirements: The Escalator Object shall support Escalator\_Mode property. Escalator runs at UP mode. Tester shall select any value for Escalator\_Mode property for testing that are supported by IUT.

#### Test Steps:

- 1. IF (Out Of Service is writable) THEN
  - WRITE Out Of Service = TRUE

**ELSE** 

MAKE (Out\_Of\_Service = TRUE)

- 2. VERIFY Out\_Of\_Service = TRUE
- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)
- 4. WRITE Escalator Mode = DOWN
- 5. VERIFY Escalator\_Mode = DOWN
- 6. CHECK (the escalator or slanted passenger conveyor is still moving upward)
- 7. MAKE (the escalator to move from downward to upward)
- 8. VERIFY Escalator Mode = DOWN
- 9. IF (Out\_Of\_Service is writable) THEN

WRITE Out Of Service = FALSE

**ELSE** 

MAKE (Out\_Of\_Service = FALSE)

- 10. VERIFY Out Of Service = FALSE
- 11. VERIFY Status\_Flags = (?, ?, ?, FALSE)

### 7.3.2.X46.1.5 Operation\_Direction Tracks Escalator\_Mode Test

Purpose: To verify the linking of Operation\_Direction property and Escalator\_Mode property of Escalator object

Test Concept: Operation\_Direction property i.e. the direction and speed in which this escalator is presently moving corresponds to the Escalator\_Mode property of Escalator object

### Test Steps:

- IF (Escalator\_Mode = STOP) THEN
   VERIFY Operation\_Direction = STOPPED
- 2. IF (Escalator\_Mode = UP) THEN

VERIFY Operation\_Direction = UP\_RATED\_SPEED | UP\_REDUCED\_SPEED

3. IF (Escalator\_Mode = DOWN) THEN

VERIFY Operation\_Direction = DOWN\_RATED\_SPEED | DOWN\_REDUCED\_SPEED

#### 7.3.2.X46.1.6 Energy\_Meter\_Ref Property Test

Purpose: To verify linking of Energy Meter property and Energy Meter Ref property.

Test Concept: If the Energy\_Meter\_Ref property is present and initialized with and Object (contains an instance other than 4194303), then the Energy\_Meter property, if present, shall have a value of 0.0. If Energy\_Meter\_Ref property is un-initialized, then the Energy\_Meter property shall have any valid value.

#### Test Steps:

IF (Energy\_Meter\_Ref is present and initialized with instance other than 4194303) THEN
 VERIFY Energy\_Meter = 0.0
 ELSE
 VERIFY Energy\_Meter = (Any Valid Value)

#### 7.3.2.X46.1.7 CHANGE\_OF\_STATE for Passenger\_Alarm (ConfirmedEventNotification)

Purpose: To verify the correct operation of the CHANGE\_OF\_STATE event algorithm. This test applies to Event Enrollment objects with an Event\_Type of CHANGE\_OF\_STATE and to intrinsic event reporting for Escalator and Lift objects.

Test Concept: The object begins the test in a NORMAL state. pMonitoredValue is set to TRUE. After pTimeDelay the object shall enter the OFFNORMAL state and transmit an event notification message. pMonitoredValue is set to FALSE corresponding to a NORMAL state. After pTimeDelayNormal the object shall enter the NORMAL state and transmit an event notification message

Configuration Requirements: The IUT shall be configured such that the Event\_Enable property has a value of TRUE for the TO-OFFNORMAL, TO-FAULT and TO-NORMAL transitions. The Issue\_Confirmed\_Notifications parameter shall have a value of TRUE. The event-generating objects shall be in a NORMAL state at the start of the test. If a Notification Class object is being used to configure recipient information the value of the Transitions parameter for all recipients shall be (TRUE, TRUE). If present in the object being tested, the Event\_Detection\_Enable property shall have a value of TRUE, Event\_Algorithm\_Inhibit shall have a value of FALSE.

### Test Steps:

- 1. VERIFY pCurrentState = NORMAL
- 2. I F (the object, or referenced object, if using Event Enrollment, is an Escalator or Lift object with Passenger\_Alarm property) THEN
- 3. MAKE (pMonitoredValue (Passenger\_Alarm) = TRUE)
- 4. WAIT (pTimeDelay)
- 5. BEFORE Notification Fail Time

RECEIVE ConfirmedEventNotification-Request,

'Process Identifier' = (any valid process ID),

```
'Initiating Device Identifier' =
                                    IUT,
'Event Object Identifier' = (the intrinsic reporting object being tested or the EventEnrollment
object being tested).
'Time Stamp' =
                                    (T1, the current local time or sequence number),
```

'Notification Class' = (the configured notification class),

(the value configured to correspond to a TO-OFFNORMAL transition), 'Priority' =

CHANGE\_OF\_STATE, 'Event Type' =

'Message Text' = (optional, any valid message text),

'Notify Type' = EVENT | ALARM, 'AckRequired' = TRUE | FALSE, 'From State' = NORMAL, 'To State' = OFFNORMAL,

'Event Values' = (pMonitoredValue, pStatusFlags)

- 6. TRANSMIT BACnet-SimpleACK-PDU
- 7. VERIFY pStatusFlags = (TRUE, FALSE, ?, ?)
- 8. VERIFY pCurrentState = OFFNORMAL
- 9. VERIFY Event Time Stamps = (T1, \*, \*)
- 10. MAKE (pMonitoredValue (Passenger\_Alarm) = FALSE)
- 11. WAIT (pTimeDelayNormal)
- 12. BEFORE Notification Fail Time

RECEIVE ConfirmedEventNotification-Request,

(any valid process ID), 'Process Identifier' =

'Initiating Device Identifier' = **IUT** 

'Event Object Identifier' = (the intrinsic reporting object being tested or the

EventEnrollment object being tested),

'Time Stamp' = (T2, the current local time or sequence number),

'Notification Class' = (the configured notification class),

'Priority' = (the value configured to correspond to a TO-NORMAL

transition),

'Event Type' = CHANGE OF STATE,

'Message Text' = (optional, any valid message text),

'Notify Type' = EVENT | ALARM, 'AckRequired' = TRUE | FALSE, 'From State' = OFFNORMAL, 'To State' = NORMAL,

'Event Values' = (pMonitoredValue, pStatusFlags)

- 13. TRANSMIT BACnet-SimpleACK-PDU
- 14. VERIFY pStatusFlags = (FALSE, FALSE, ?, ?)
- 15. VERIFY pCurrentState = NORMAL
- 16. VERIFY Event\_Time\_Stamps = (T1, \*, T2)

#### 7.3.2.X46.1.8 CHANGE OF STATE for Passenger Alarm (UnconfirmedEventNotification)

Purpose: To verify the correct operation of the CHANGE\_OF\_STATE event algorithm. This test applies to Event Enrollment objects with an Event Type of CHANGE OF STATE and to intrinsic event reporting for Escalator and Lift objects.

Test Concept: The object begins the test in a NORMAL state. pMonitoredValue is set to TRUE. After pTimeDelay the object shall enter the OFFNORMAL state and transmit an event notification message. pMonitoredValue is set to FALSE corresponding to a NORMAL state. After pTimeDelayNormal the object shall enter the NORMAL state and transmit an event notification message

Configuration Requirements: The IUT shall be configured such that the Event Enable property has a value of TRUE for the TO-OFFNORMAL, TO-FAULT and TO-NORMAL transitions. The Issue\_Confirmed\_Notifications parameter shall have a value of FALSE. The event-generating objects shall be in a NORMAL state at the start of the test. If a Notification Class object is being used to configure recipient information the value of the Transitions

parameter for all recipients shall be (TRUE, TRUE, TRUE). If present in the object being tested, the Event\_Detection\_Enable property shall have a value of TRUE, Event\_Algorithm\_Inhibit shall have a value of FALSE.

Test Steps: The test steps for this test are identical to the test steps in 7.3.2.X46.1.7 except that the ConfirmedEventNotification requests are UnconfirmedEventNotification requests and the TD does not acknowledge receiving the notifications.

[Elevator Group, Escalator, and Lift Object Tests] [In BTL Specified Tests, add clause 7.3.2.X47.1 Lift Object Tests]

#### 7.3.2.X47.1 Lift Object Tests

# 7.3.2.X47.1.1 Elevator\_Group property of Lift Object linking with Group\_Members property of Elevator Group Object

Purpose: This test verifies that Elevator\_Group property of Lift object shall have reference of Elevator Group object whose Group\_Members property contains a reference of Lift object.

Test Concept: Lift object falls under one specific Elevator Group object. The reference of Elevator Group object should be mentioned in Elevator\_Group property of Lift object. If there is no such Elevator Group object, Elevator\_Group property shall contain an object instance of 4194303.

Configuration Requirements: The Lift (L1) should present under the Elevator Group (EG1). OBJECT is any valid object type.

#### Test Steps:

- 1. VERIFY (L1), Elevator Group = (EG1)
- 2. VERIFY (EG1), Group\_Members = ((L1), .... Ln)
- 3. IF (IUT does not have reference of any such Elevator Group object) THEN VERIFY (L1), Elevator\_Group = (OBJECT, 4194303)

#### 7.3.2.X47.1.2 Car\_Moving\_Direction and Car\_Assigned\_Direction Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made for Car\_Moving\_Direction and Car\_Assigned\_Direction property and it does not control the lift operation from these properties.

Test Concept: When Out\_Of\_Service is set to TRUE, writing Car\_Moving\_Direction and Car\_Assigned\_Direction property shall not make lift to serve specified direction. Also, making lift to serve any direction shall not be updated in Car\_Moving\_Direction and Car\_Assigned\_Direction property of Lift object. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If Car\_Assigned\_Direction property is not present, then the respective test steps shall be skipped.

Configuration Requirements: 'X' and 'Y' are any valid directions supported by IUT. Tester shall select any car moving direction and car assigned direction supported by IUT.

#### Test Steps:

- IF (Out\_Of\_Service is writable) THEN
   WRITE Out\_Of\_Service = TRUE
   ELSE
   MAKE (Out\_Of\_Service = TRUE)
- 2. VERIFY Out Of Service = TRUE
- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)

- 4. WRITE Car\_Moving\_Direction = Direction X
- 5. VERIFY Car Moving Direction = Direction X
- 6. CHECK (the lift is not serving as per the Car\_Moving\_Direction property)
- 7. MAKE (the lift to move in Direction Y)
- 8. VERIFY Car Moving Direction = Direction X
- 9. WRITE Car Assigned Direction = Direction X
- 10. VERIFY Car\_Assigned\_Direction = Direction X
- 11. CHECK (the lift is not serving as per the Car\_Assigned\_Direction property)
- 12. MAKE (the lift assigned towards Direction Y)
- 13. VERIFY Car\_Assigned\_Direction = Direction X
- 14. IF (Out\_Of\_Service is writable) THEN

WRITE Out Of Service = FALSE

**ELSE** 

MAKE (Out Of Service = FALSE)

- 15. VERIFY Out Of Service = FALSE
- 16. VERIFY Status Flags = (?, ?, ?, FALSE)

#### 7.3.2.X47.1.3 Car\_Door\_Status and Landing\_Door\_Status Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made for Car\_Door\_Status and Landing\_Door\_Status property and it does not control the lift operation from these properties.

Test Concept: When Out\_Of\_Service is set to TRUE, writing Car\_Door\_Status and Landing\_Door\_Status property shall not make lift and landing doors to operate. Also, making lift and landing doors to operate shall not be updated in Car\_Door\_Status and Landing\_Door\_Status property when the Out\_Of\_Service is set to TRUE. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If Landing\_Door\_Status property is not present, then the respective test steps shall be skipped.

Configuration Requirements: Lift's Door starts in OPEN State. ARRAY INDEX = (any valid value N;  $1 \le N \le$  number of doors of a car). Universal floor number = (X = any valid floor number of the lift connected to the IUT) Tester shall select any car door status and landing door status values supported by IUT.

#### Test Steps:

- IF (Out\_Of\_Service is writable) THEN WRITE Out\_Of\_Service = TRUE
  - **ELSE**

MAKE (Out Of Service = TRUE)

- VERIFY Out\_Of\_Service = TRUE
- 3. VERIFY Status Flags = (?, ?, ?, TRUE)
- 4. WRITE Car\_Door\_Status = CLOSED, ARRAY INDEX = N
- 5. VERIFY Car\_Door\_Status = CLOSED, ARRAY INDEX = N
- 6. CHECK (the lift's car door is not operating as per the Car Door Status property)
- 7. MAKE (the lift's car door N to OPEN)
- 8. VERIFY Car\_Door\_Status = CLOSED, ARRAY INDEX = N
- 9. WRITE Landing Door Status = CLOSING, ARRAY INDEX = N. Universal floor number = X
- 10. VERIFY Landing\_Door\_Status = CLOSING, ARRAY INDEX = N
- 11. CHECK (the specified landing door is not serving as per the Landing\_Door\_Status property)
- 12. MAKE (the landing door for car door N to OPEN at Universal floor number X)
- 13. VERIFY Landing\_Door\_Status = CLOSING, ARRAY INDEX = N, Universal floor number = X
- 14. IF (Out\_Of\_Service is writable) THEN

WRITE Out Of Service = FALSE

**ELSE** 

MAKE (Out\_Of\_Service = FALSE)

15. VERIFY Out\_Of\_Service = FALSE

16. VERIFY Status\_Flags = (?, ?, ?, FALSE)

# 7.3.2.X47.1.4 Car\_Position and Next\_Stopping\_Floor Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made in Car\_Position and Next\_Stopping\_Floor property and also it does not control the lift operation from these properties.

Test Concept: When the Out\_Of\_Service is set to TRUE, writing Car\_Position and Next\_Stopping\_Floor property shall not make lift to update its car position and next stopping floor. Also, while making lift's car position and next stopping floor change from current value, it shall not get updated to Car\_Position and Next\_Stopping\_Floor property of the Lift object. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If Next\_Stopping\_Floor property is not present, then the respective test steps shall be skipped.

Configuration Requirements: Lift's current position (floor) is A. Universal floor number = (X, Y, A, B, C = any valid floor number of the lift connected to the IUT). Tester shall select any floor number supported by IUT for this test

#### Test Steps:

- IF (Out\_Of\_Service is writable) THEN
   WRITE Out\_Of\_Service = TRUE
   ELSE
   MAKE (Out\_Of\_Service = TRUE)
- 2. VERIFY Out Of Service = TRUE
- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)
- 4. WRITE Car\_Position = Y
- 5. VERIFY Car Position = Y
- 6. CHECK (the lift still stands at the floor A)
- 7. MAKE (the lift to stand at the floor X)
- 8. VERIFY Car\_Position = Y
- 9. WRITE Next\_Stopping\_Floor = C
- 10. VERIFY Next Stopping Floor = C
- 11. CHECK (the lift is not moving towards floor C and it still stands at floor X)
- 12. MAKE (the lift to move from floor X to reach floor B)
- 13. VERIFY Next Stopping Floor = C
- 14. IF (Out\_Of\_Service is writable) THEN
  WRITE Out\_Of\_Service = FALSE
  ELSE
  MAKE (Out\_Of\_Service = FALSE)
- 15. VERIFY Out Of Service = FALSE
- 16. VERIFY Status\_Flags = (?, ?, ?, FALSE)

#### 7.3.2.X47.1.5 Passenger\_Alarm and Fault\_Signals Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made for Passenger\_Alarm and Fault\_Signals property and it does not control the lift operation from these properties.

Test Concept: When the Out\_Of\_Service is set to TRUE, writing Passenger\_Alarm and Fault\_Signals property shall not make lift to update its alarm and fault status. Also, while making lift's fault and alarm status change from current value, it shall not get updated to Passenger\_Alarm and Fault\_Signals property of the Lift object. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If Fault\_Signals property is not present, then the respective test steps shall be skipped.

Configuration Requirements: Lift has no alarm or fault at the start of test. Tester shall select any value for Fault\_Signals property testing that is supported by IUT.

# Test Steps:

- IF (Out\_Of\_Service is writable) THEN WRITE Out\_Of\_Service = TRUE ELSE
  - MAKE (Out\_Of\_Service = TRUE)
- 2. VERIFY Out\_Of\_Service = TRUE
- 3. WRITE Passenger\_Alarm = TRUE
- 4. VERIFY Passenger\_Alarm = TRUE
- 5. CHECK (the lift's alarm is not triggered)
- 6. MAKE (the lift to move from Alarm to normal state)
- 7. VERIFY Passenger Alarm = TRUE
- 8. WRITE Fault\_Signals = CALL\_BUTTON\_STUCK
- 9. VERIFY Fault\_Signals = CALL\_BUTTON\_STUCK
- 10. CHECK (the lift does not have any fault into it)
- 11. MAKE (the lift to have POSITION LOST fault)
- 12. VERIFY Fault\_Signals = CALL\_BUTTON\_STUCK
- 13. IF (Out\_Of\_Service is writable) THEN
  WRITE Out\_Of\_Service = FALSE
  ELSE
  MAKE (Out\_Of\_Service = FALSE)
- 14. VERIFY Out Of Service = FALSE

#### 7.3.2.X47.1.6 Making Car Call, Car Mode & Car Door Command Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made for Making\_Car\_Call, Car\_Mode & Car\_Door\_Command property and also it does not control the lift operation from these properties.

Test Concept: When Out\_Of\_Service is set to TRUE, writing Making\_Car\_Call, Car\_Mode & Car\_Door\_Command property shall not make lift to serve specified floor, to set the mode and to execute car door commands. Also, making lift to serve different floors, to operate at different modes and for various car door commands shall not be updated in Making\_Car\_Call, Car\_Mode & Car\_Door\_Command properties of Lift Object. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If any of the Making\_Car\_Call, Car\_Mode or Car\_Door\_Command property is not present, then the test steps for that specific property shall be skipped.

Configuration Requirements: Car\_Mode is NORMAL and Car\_Door\_Command is CLOSE at the start of the test. ARRAY INDEX = (any valid value N;  $1 \le N \le$  number of doors of a car). Universal floor number = (X, Y = any valid floor number of the lift connected to the IUT). Tester shall select any car door command or car mode supported by IUT while testing.

# Test Steps:

- IF (Out\_Of\_Service is writable) THEN WRITE Out\_Of\_Service = TRUE ELSE
- MAKE (Out\_Of\_Service = TRUE)
  2. VERIFY Out\_Of\_Service = TRUE
- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)
- 4. WRITE Making Car Call = any valid floor X, ARRAY INDEX = N
- 5. VERIFY Making\_Car\_Call = X, ARRAY INDEX = N
- 6. CHECK (the lift is not serving as per value X in Making\_Car\_Call property)
- 7. MAKE (the lift to serve call at floor Y for car door N)

- 8. VERIFY Making\_Car\_Call = X, ARRAY INDEX = N
- 9. WRITE Car\_Door\_Command = OPEN, ARRAY INDEX = N
- 10. VERIFY Car Door Command = OPEN, ARRAY INDEX = N
- 11. CHECK (the lift's car door N is not opening as per the Car\_Door\_Command property)
- 12. MAKE (the lift to CLOSE at the car door N from OPEN or NONE)
- 13. VERIFY Car Door Command = OPEN, ARRAY INDEX = N
- 14. WRITE Car Mode = HOMING
- 15. VERIFY Car Mode = HOMING
- 16. CHECK (the lift is not moving into HOMING mode)
- 17. MAKE (the lift into PARKING mode)
- 18. VERIFY Car Mode = HOMING
- 19. IF (Out\_Of\_Service is writable) THEN WRITE Out\_Of\_Service = FALSE ELSE
  - MAKE (Out\_Of\_Service = FALSE)
- 20. VERIFY Out\_Of\_Service = FALSE
- 21. VERIFY Status\_Flags = (?, ?, ?, FALSE)

#### 7.3.2.X47.1.7 Assigned\_Landing\_Call and Registered\_Car\_Call Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made for Assigned\_Landing\_Call and Registered\_Car\_Call property and it does not control the lift operation from these properties.

Test Concept: When Out\_Of\_Service is set to TRUE, writing Assigned\_Landing\_Call and Registered\_Car\_Call property shall not make lift to serve specified floors and direction. Also, making lift to serve any floors and direction shall not be updated in Assigned\_Landing\_Calls and Registered\_Car\_Call property of Lift object. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If any of the Assigned\_Landing\_Calls and Registered\_Car\_Call property is not present, then the test steps for that specific property shall be skipped.

Configuration Requirements: ARRAY INDEX = (any valid value N;  $1 \le N \le$  number of doors of a car). Universal floor number = (A, B, X1...n, Y1...n = any valid floor number of the lift connected to the IUT). P, Q is any valid direction supported by IUT.

#### Test Steps:

- IF (Out\_Of\_Service is writable) THEN
   WRITE Out\_Of\_Service = TRUE
   ELSE
   MAKE (Out\_Of\_Service = TRUE)
- 2. VERIFY Out Of Service = TRUE
- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)
- 4. WRITE Assigned\_Landing\_Calls = (Floor A, Direction P), ARRAY INDEX = N
- 5. VERIFY Assigned\_Landing\_Calls = (Floor A, Direction P), ARRAY INDEX = N
- 6. CHECK (the lift is not serving as per the values of Assigned\_Landing\_Calls property)
- 7. MAKE (the lift to serve landing call at Floor B, Direction Q for car door N)
- 8. VERIFY Assigned\_Landing\_Calls = (Floor A, Direction P), ARRAY INDEX = N
- 9. WRITE Registered\_Car\_Call = (X1, X2, X3, X4...Xn), ARRAY INDEX = N
- 10. VERIFY Registered\_Car\_Call = (X1, X2, X3, X4...Xn), ARRAY INDEX = N
- 11. CHECK (the lift is not serving as per the Registered\_Car\_Call property)
- 12. MAKE (the lift to serve calls at Floor (Y1, Y2, Y3....Yn) for car door N)
- 13. VERIFY Registered\_Car\_Call = (X1, X2, X3, X4...Xn), ARRAY INDEX = N
- 14. IF (Out\_Of\_Service is writable) THEN WRITE Out\_Of\_Service = FALSE

ELSE

MAKE (Out\_Of\_Service = FALSE)

- 15. VERIFY Out\_Of\_Service = FALSE
- 16. VERIFY Status Flags = (?, ?, ?, FALSE)

# 7.3.2.X47.1.8 Car\_Door\_Zone and Car\_Load Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made for Car\_Door\_Zone and Car\_Load property and it does not control the lift operation from these properties.

Test Concept: When the Out\_Of\_Service is set to TRUE, writing Car\_Door\_Zone and Car\_Load property shall not make lift update its car door zone and its load. Also, while making lift's car to enter to a particular door zone where door opening is permitted and having a specific weight of lift car shall not get updated to Car\_Door\_Zone and Car\_Load properties of the Lift object. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If any of the Car\_Door\_Zone and Car\_Load property is not present, then the test steps for that specific property shall be skipped.

Configuration Requirements: Lift is stopped at any floor in the specified car door zone and having X units of weight. Tester shall select any weight within the permissible limit of the IUT while testing the Car\_Load property.

# Test Steps:

- IF (Out\_Of\_Service is writable) THEN
   WRITE Out\_Of\_Service = TRUE
   ELSE
  - MAKE (Out\_Of\_Service = TRUE)
- 2. VERIFY Out Of Service = TRUE
- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)
- 4. WRITE Car Door Zone = FALSE
- 5. VERIFY Car\_Door\_Zone = FALSE
- 6. CHECK (the lift's car door zone remains unchanged independent of value written)
- 7. MAKE (the lift's car door to door opening permitted zone)
- 8. VERIFY Car\_Door\_Zone = FALSE
- 9. WRITE Car Load = X+1 units
- 10. VERIFY Car Load = X+1 units
- 11. CHECK (the car load is X units)
- 12. MAKE (the lift car load to X+2)
- 13. VERIFY Car Load = X+1 units
- 14. IF (Out\_Of\_Service is writable) THEN

WRITE Out\_Of\_Service = FALSE

**ELSE** 

MAKE (Out Of Service = FALSE)

- 15. VERIFY Out Of Service = FALSE
- 16. VERIFY Status\_Flags = (?, ?, ?, FALSE)

# 7.3.2.X47.1.9 Energy\_Meter and Car\_Drive\_Status Tracking Test

Purpose: To verify that when Out\_Of\_Service property is set to TRUE for the monitored Lift object, it does not track the changes made for Energy\_Meter and Car\_Drive\_Status property and it does not control the lift operation from these properties.

Test Concept: When the Out\_Of\_Service is set to TRUE, writing Energy\_Meter and Car\_Drive\_Status property shall not make lift to update its energy value and car drive status. Also, while making lift's energy and car drive status change from current value, it shall not get updated to Energy\_Meter and Car\_Drive\_Status property of the Lift object. Out\_Of\_Service property of the Lift object is set to TRUE in the beginning of the test. If any of the Energy\_Meter and Car\_Drive\_Status property is not present, then the test steps for that specific property shall be skipped.

Configuration Requirements: Lift is stopped at any floor, i.e. car drive status is stationary. Lift is having energy meter value = X. Tester shall select any value for energy meter Y; Y < 99999 or permitted by IUT. Tester shall select any car drive status supported by IUT.

#### Test Steps:

- IF (Out\_Of\_Service is writable) THEN
   WRITE Out\_Of\_Service = TRUE
   ELSE
   MAKE (Out\_Of\_Service = TRUE)
- 2. VERIFY Out Of Service = TRUE
- 3. VERIFY Status\_Flags = (?, ?, ?, TRUE)
- 4. WRITE Energy\_Meter = Y
- 5. VERIFY Energy\_Meter = Y
- 6. CHECK (the lift's energy consumption is having value = X or value other than Y)
- 7. MAKE (the lift's energy consumption value = Z)
- 8. VERIFY Energy\_Meter = Y
- 9. WRITE Car\_Drive\_Status = BRAKING
- 10. VERIFY Car\_Drive\_Status = BRAKING
- 11. CHECK (the lift's car drive status is STATIONARY)
- 12. MAKE (the lift's car drive status to ACCELERATE)
- 13. VERIFY Car\_Drive\_Status = BRAKING
- 14. IF (Out\_Of\_Service is writable) THEN WRITE Out\_Of\_Service = FALSE ELSE

MAKE (Out\_Of\_Service = FALSE)

- 15. VERIFY Out Of Service = FALSE
- 16. VERIFY Status\_Flags = (?, ?, ?, FALSE)

# 7.3.2.X47.1.10 Making\_Car\_Call and Registered\_Car\_Call Test

Purpose: To verify that the values written into Making\_Car\_Call property of lift object reflects in its Registered\_Car\_Call property at the same door side array index.

Test Concept: Making\_Car\_Call property of Lift (L1) object being tested is subjected for car calls provided by means of passenger requesting for car stop or by means of writing the property. The Registered\_Car\_Call property value at a specified array index is checked to verify that it is same as that of value provided to Making\_Car\_Call property.

Configuration Requirements: For below steps 'Array Index' = (any valid value N;  $1 \le N \le$  number of doors of a car) and 'Property Value' = (any valid value X;  $X \le$  highest universal floor number of the lift)

#### Test Steps:

```
    IF (Making_Car_Call is writable) THEN
        WRITE (L1), Making_Car_Call = X, ARRAY INDEX = N
        ELSE
        MAKE (Making_Car_Call = (Value of X), ARRAY INDEX = N)
```

- 2. VERIFY (L1), Making\_Car\_Call = X, ARRAY INDEX = N
- 3. VERIFY (L1), Registered\_Car\_Call = X, ARRAY INDEX = N

Notes to Tester: Registered\_Car\_Call property may contain other additional entries.

#### 7.3.2.X47.1.11 Array Size of the Lift Object properties based on car door size.

Purpose: To verify that the size of the Car\_Door\_Text, Assigned\_Landing\_Calls, Making\_Car\_Call, Registered\_Car\_Call, Car\_Door\_Status, Car\_Door\_Command and Landing\_Door\_Status array corresponds to the number of car doors present in the lift car and all are of same size.

Test Concept: Above properties will be verified for the array index 0 equals the number of car doors present in the Lift (L1). If change of car door size is possible, change and REPEAT all the steps else skip. If any of above properties are not present, then skip and proceed with the test for available properties.

# Test Steps:

- 1. VERIFY (L1), Car\_Door\_Text = (Number of car doors present in the Lift), ARRAY INDEX = 0
- 2. VERIFY (L1), Assigned Landing Calls = (Number of car doors present in Lift), ARRAY INDEX = 0
- 3. VERIFY (L1), Making Car Call = (Number of car doors present in the Lift), ARRAY INDEX = 0
- 4. VERIFY (L1), Registered\_Car\_Call = (Number of car doors present in the Lift), ARRAY INDEX = 0
- 5. VERIFY (L1), Car Door Status = (Number of car doors present in the Lift), ARRAY INDEX = 0
- 6. VERIFY (L1), Car\_Door\_Command = (Number of car doors present in the Lift), ARRAY INDEX = 0
- 7. VERIFY (L1), Landing\_Door\_Status = (Number of car doors present in the Lift), ARRAY INDEX = 0
- 8. CHECK (Array index 0 of all these properties shall be same)

# 7.3.2.X47.1.12 Landing\_Door\_Status Tracks Car\_Door\_Status Test

Purpose: To verify that the status of Car\_Door\_Status property of lift is as same as that of the Landing\_Door\_Status property at a particular floor.

Test Concept: Car\_Door\_Status property of Lift (L1) object is subjected for different BACnetDoorStatus provided by changing the door status of real time lift connected to IUT or writing to it. The door side and floor number of the lift is considered in this case. The Landing\_Door\_Status property value at a specified array index (door size) for a particular floor (where lift car is currently present) is checked to verify that it is same as that of the status provided to Car\_Door\_Status property. If Landing\_Door\_Status property is not present, then this test shall be skipped.

Configuration Requirements: For below steps 'Array Index' = (any valid value N;  $1 \le N \le$  number of doors of a car). Y = (any valid floor number of the lift connected to the IUT). Tester shall select any value X for Car\_Door\_Status supported by IUT.

# Test Steps:

- IF (Car\_Door\_Status is writable) THEN
   WRITE (L1), Car\_Door\_Status = X, ARRAY INDEX = N
   ELSE
   MAKE (Car\_Door\_Status = (Value of X), ARRAY INDEX = N)
- 2. VERIFY (L1), Car Door Status = X, ARRAY INDEX = N
- 3. VERIFY (L1), Car Position = Y,
- 4. VERIFY (L1), Landing\_Door\_Status = X, ARRAY INDEX = N
- 5. CHECK (Landing\_Door\_Status property value is X only for the Universal floor number Y)

# 7.3.2.X47.1.13 Highest Universal floor number linking to Car\_Position and Next\_Stopping\_Floor properties

Purpose: This test verifies that the highest universal floor number of the Lift object can be the maximum value of above properties depending on the floor numbers

Test Concept: Lift Object (L1) Properties Car\_Position and Next\_Stopping\_Floor will be written with the value of highest universal floor number and greater. If there is a physical lift or any alternate way for changing the highest universal floor number, change and REPEAT all the steps else omit. If any of the dependable properties are not writable, then skip the specific property from the test.

This test shall be skipped if Floor\_Text property is not present.

Configuration Requirements: For below steps 'Property Value' = (Y = highest universal floor number of the lift connected to the IUT). If Next\_Stopping\_Floor property is not present, then respective steps shall be skipped.

#### Test Steps:

```
1. VERIFY (L1), Floor\_Text = Y, ARRAY INDEX = 0
```

2. IF (Car\_Position is writable) THEN

WRITE (L1), Car\_Position = Y

VERIFY (L1), Car\_Position = Y

3. TRANSMIT WriteProperty-Request,

'Object Identifier' = (L1),

'Property Identifier' = Car Position,

'Property Value' = Y+1

4. RECEIVE BACnet-Error-PDU,

'Error Class' = PROPERTY,

'Error Code' = VALUE OUT OF RANGE

5. IF (Next\_Stopping\_Floor is writable) THEN

WRITE (L1), Next\_Stopping\_Floor = Y

VERIFY (L1), Next\_Stopping\_Floor = Y

6. TRANSMIT WriteProperty-Request,

'Object Identifier' = (L1),

'Property Identifier' = Next\_Stopping\_Floor,

'Property Value' = Y+1

7. RECEIVE BACnet-Error-PDU,

'Error Class' = PROPERTY,

'Error Code' = VALUE OUT OF RANGE

# 7.3.2.X47.1.14 Highest Universal floor number linking to Assigned\_Landing\_Calls, Making\_Car\_Call and Registered Car Call properties

Purpose: This test verifies that the highest universal floor number of the Lift object can be the maximum value of above properties depending on the floor numbers

Test Concept: Lift Object (L1) Properties Assigned\_Landing\_Calls, Making\_Car\_Call and Registered\_Car\_Call will be written with the value of highest universal floor number and greater. If there is a physical lift or any alternate way for changing the highest universal floor number, change and REPEAT all the steps else omit. If any of the dependable properties are not writable, then skip the specific property from the test. This test shall be skipped if Floor\_Text property is not present.

Configuration Requirements: For below steps 'Array Index' = (any valid value N;  $1 \le N \le$  number of doors of a car) and 'Property Value' = (Y = highest universal floor number of the lift). If any of the dependable properties are not writable, then MAKE Out\_Of\_Service TRUE and then write, else skip the specific property from the test.

# Test Steps:

```
1. VERIFY (L1), Floor Text = Y, ARRAY INDEX = 0
```

2. IF (Making\_Car\_Call is writable) THEN

WRITE (L1), Making\_Car\_Call = Y, ARRAY INDEX = N VERIFY (L1), Making\_Car\_Call = Y, ARRAY INDEX = N,

3. TRANSMIT WriteProperty-Request,

'Object Identifier' = (L1),

'Property Identifier' = Making Car Call,

'Property Value' = Y+1

4. RECEIVE BACnet-Error-PDU,

'Error Class' = PROPERTY,

```
'Error Code' = VALUE OUT OF RANGE
```

5. IF (Registered Car Call is writable) THEN

WRITE (L1), Registered Car Call = Y, ARRAY INDEX = N

- 6. VERIFY (L1), Registered\_Car\_Call = Y, ARRAY INDEX = N,
- 7. TRANSMIT WriteProperty-Request,

'Object Identifier' = (L1),

'Property Identifier' = Registered\_Car\_Call,

'Property Value' = Y+1

8. RECEIVE BACnet-Error-PDU,

'Error Class' = PROPERTY,

'Error Code' = VALUE\_OUT\_OF\_RANGE

9. IF (Assigned Landing Call is writable) THEN

WRITE (L1), Assigned\_Landing\_Call = (Y, at Z Direction), ARRAY INDEX = N

- 10. VERIFY (L1), Assigned\_Landing\_Call = (Y, at Z Direction), ARRAY INDEX = N
- 11. TRANSMIT WriteProperty-Request,

'Object Identifier' = (L1),

'Property Identifier' = Assigned\_Landing\_Call,

'Property Value' = (Y+1, at Z Direction)

12. RECEIVE BACnet-Error-PDU,

'Error Class' = PROPERTY,

'Error Code' = VALUE OUT OF RANGE

#### 7.3.2.X47.1.15 Energy\_Meter\_Ref Property Tests

Purpose: To verify linking of Energy\_Meter property and Energy\_Meter\_Ref property.

Test Concept: If the Energy\_Meter\_Ref property of Lift object (L1) is present and initialized (contains an instance other than 4194303), then the Energy\_Meter property, if present, shall have a value of 0.0. If Energy\_Meter\_Ref is present and is un-initialized, then the value of Energy\_Meter property shall have any valid value.

#### Test Steps:

1. IF (Energy\_Meter\_Ref is present and initialized with instance other than 4194303) THEN VERIFY Energy\_Meter = 0.0 ELSE

VERIFY Energy Meter = (Any Valid Value)

# 7.3.2.X47.1.16 Higher\_Deck and Lower\_Deck Tests

Purpose: To verify that the Higher\_Deck and Lower\_Deck property of the Lift Object is referencing the Lift object that refers the car deck above and below the car deck represented by this Lift object.

Test Concept: The IUT under test is configured to have a 3-deck lift having 3 Lift Objects. The Higher\_Deck and Lower\_Deck Property of the Lift object is then read to verify that it is representing the correct Lift Object instances. If there is no higher deck or lower deck, then the object instance shall be 4194303.

Configuration Requirements: The IUT under test is configured to have a 3-deck lift having 3 Lift Object instances: higher deck (L1), middle deck (L2) and lower deck (L3). If the IUT have 2 Deck lift having 2 Lift Objects, then the test steps shall be modified accordingly and executed.

#### Test Steps:

- 1. VERIFY (L1), Higher Deck = (OBJECT, 4194303),
- 2.  $VERIFY (L1), Lower\_Deck = (L2),$
- 3. VERIFY (L2), Higher\_Deck = (L1),
- 4. VERIFY (L2), Lower\_Deck = (L3),

- 5. VERIFY (L3), Higher\_Deck = (L2),
- 6. VERIFY (L3), Lower Deck = (OBJECT, 4194303)

# 7.3.2.X47.1.17 Linking of Assigned\_Landing\_Calls property of Lift Object to Landing\_Calls property of Elevator Group

Purpose: To verify that the Landing\_Calls property of Elevator Group also represents the active calls present in the Assigned\_Landing\_Calls property of the Lift object.

Test Concept: An Elevator Group is available, supports Landing\_Calls property, and it contains at least one Lift object within this group. Assigned\_Landing\_Calls property of the Lift is updated with the Floor number and direction for the lift. Landing\_Calls property of the Elevator Group object shall have the value as per the Assigned\_Landing\_Calls represented by this Lift object. For implementations where it is not possible to write to Assigned\_Landing\_Calls, this test shall be skipped.

Configuration Requirements: The Lift (L1) should be present in the Group\_Members property of Elevator Group (EG1). Lowest universal floor number of the lift < A < Highest universal floor number of the lift. Lowest universal floor number of the lift. B = (UP | DOWN | UP\_AND\_DOWN) and C = (B | UP\_AND\_DOWN).

# Test Steps:

- IF (Assigned\_Landing\_Calls is writable) THEN
   WRITE Assigned\_Landing\_Calls = (Floor Number A, Direction B)
- 2. VERIFY (L1), Assigned\_Landing\_Calls = (Floor Number A, Direction B)
- 3. VERIFY (EG1), Landing\_Calls = (Floor Number A, Direction C | Destination X)

Notes to Tester: Landing\_Calls property may contain other entries from same lift or different lifts connected under same Elevator Group.

[Elevator Group, Escalator, and Lift Object Tests] [In BTL Specified Tests, add to Clause 8.5.X1]

# 8.5.X1 CHANGE OF RELIABILITY Tests

#### 8.5.X1.15 Change Of Reliability FAULT-to-FAULT transitions in FAULT LISTED

Purpose: To verify the correct operation of FAULT-to-FAULT transitions in FAULT\_LISTED event algorithm.

Test Concept: Select a fault detecting object O1 which is configured to use the FAULT\_LISTED algorithm. Ensure that a fault condition exists in the object. Set pMonitoredList to FV1, any set of non-empty values different from the current set of values. Verify the correct transition is generated. The fault condition is removed by setting pMonitoredList to empty, a value which indicates NO FAULT DETECTED and verify the correct transition is generated.

Configuration Requirements: O1 is configured to detect faults and to report those using unconfirmed event notifications. O1 is initially configured to have a fault conditions present by pMonitoredList containing a non-empty value, and has an Event State of FAULT. FV1 is a value or set of values for pMonitoredList, and which the IUT will support in the pMonitoredList value. An empty pMonitoredList does not indicate a fault condition.

# Test Steps:

```
1. VERIFY pCurrentReliability = FAULTS_LISTED
    VERIFY Event State = FAULT
   IF (pMonitoredList is writable) THEN
        WRITE pMonitoredList = FV1
    ELSE
        MAKE (pMonitoredList = FV1)
   BEFORE Notification Fail Time
        RECEIVE UnconfirmedEventNotification-Request,
                 'Process Identifier' =
                                                  (any valid process Identifier),
                 'Initiating Device Identifier' =
                                                  IUT
                 'Event Object Identifier' =
                                                  O1
                 'Time Stamp' =
                                                  (the current local time or sequence number),
                 'Notification Class' =
                                                  (the notification class configured for O1),
                 'Priority' =
                                                  (the value configured for the transition).
                 'Event Type' =
                                                  CHANGE_OF_RELIABILITY,
                 'Message Text' =
                                                  (optional, any valid message text),
                 'Notify Type' =
                                                  ALARM | EVENT,
                 'AckRequired' =
                                                  TRUE | FALSE,
                 'From State' =
                                                  FAULT,
                 'To State' =
                                                  FAULT.
                 'Event Values' =
                                                  (FAULT_LISTED,
                                                   (T, T, ??),
                                                   (A list of valid values for properties required to be reported
                                                   for O1, and 0 or more other properties of O1)
5. VERIFY pCurrentReliability = FAULTS LISTED
```

VERIFY Event State = FAULT

```
IF (pMonitoredList is writable) THEN
    WRITE pMonitoredList = {}
ELSE
```

MAKE (pMonitoredList = { })

**BEFORE Notification Fail Time** 

RECEIVE UnconfirmedEventNotification-Request,

'Process Identifier' = (any valid process Identifier), 'Initiating Device Identifier' = IUT 'Event Object Identifier' = O1

'Time Stamp' = (the current local time or sequence number),
'Notification Class' = (the notification class configured for O1),
'Priority' = (the value configured for the transition),

'Event Type' = CHANGE\_OF\_RELIABILITY, 'Message Text' = (optional, any valid message text),

'Notify Type' = ALARM | EVENT, 'AckRequired' = TRUE | FALSE, 'From State' = FAULT, 'To State' = NORMAL,

'Event Values' = ( NO FAULT DETECTED,

(F, F, ??),

(A list of valid values for properties required to be reported

for O1, and 0 or more other properties of O1)

9. VERIFY pCurrentReliability = NO\_FAULT\_DETECTED

10. VERIFY Event\_State = NORMAL

[Network Port Object Tests] [Add into clause 9.18.1]

#### 9.18.1 Positive ReadProperty Service Execution Tests

#### 9.18.1.X5 ReadProperty of the Network Port Object using the Unknown Instance

Purpose: Verify that the IUT selects the correct object when it receives Network Port with special object instance of 4194303.

Test Concept: Execute a Read service request specifying 'Object Identifier' = (Network Port, 4194303). The responding BACnet-user shall treat the Object Identifier as if it correctly matched the local Network Port object representing the network port through which the request was received.

Configuration Requirements: Let X be the instance numbers of Network Port object (can be same or different objects) for the IUT. If the Protocol\_Revision claimed is less than 17, this test shall be skipped.

#### Test Steps:

1. TRANSMIT ReadProperty-Request,

'Object Identifier' = (Network Port, 4194303),

'Property Identifier' = Object-Identifier

2. RECEIVE ReadProperty-ACK,

'Object Identifier' = (Network Port, X), 'Property Identifier' = Object-Identifier, 'Property Value' = (Network Port, X)

3. TRANSMIT ReadProperty-Request through the same port as above,

'Object Identifier' = (Network Port, 4194303),

'Property Identifier' = (P: any valid property which is present in the same local Network Port object as bove)

4. RECEIVE ReadProperty-ACK,

'Object Identifier' = (Network Port, X),

'Property Identifier' = P,

'Property Value' = (value of P from the local Network Port object representing the network port through which the request was received)

Passing Result: The IUT shall respond as indicated conveying the value from a local Network Port object representing the network port through which the request was received.

[Network Port Object Tests]

[In BTL Specified Tests, add test into 14.3]

[All other 14.3 Write-BDT tests need to have a conditionality added to them based on the IUT's Protocol\_Revision being less than 17]

# 14.3 Broadcast Distribution Table Operations

#### 14.3.X1 Write-BDT service is required to return Write-BDT-NAK

Reason for Change: Clause J.4.4.2 mandates a change and that all devices claiming Protocol\_Revision >= 17, shall behave in this changed way.

Purpose: To verify that any IUT with Protocol\_Revision claimed as 17 or higher, will return Write-Broadcast-Distribution-Table NAK to every Write-Broadcast-Distribution-Table request.

Configuration Requirements: If the Protocol\_Revision claimed is less than 17, this test shall be skipped.

Test Steps:

- 1. TRANSMIT Write-Broadcast-Distribution-Table
- 2. RECEIVE BVLC-Result,

'Result Code' = Write-Broadcast-Distribution-Table NAK

[Network Port Object Tests]
[In BTL Specified Tests, add test into 14.3]

#### 14.3.X2 Broadcast-Distribution-Table Holds at Least 5 Entries

Reason For Change: NM-BBMDC-B specifically mandates this capacity behavior is supported by the product.

Purpose: Verify that IUT implements capacity mandated for the product by NM-BBMDC-B.

Test Concept: Fill the Broadcast\_Distribution\_Table with at least five distinct peer BBMDs entries (in addition to the entry containing the address of itself in the table).

Configuration Requirements: In a device claiming Protocol\_Revision 16 or less, the means by which the product's Broadcast-Distribution-Table is configured is not restricted to BACnet network transmissions, and can be through the product's end-user interface.

Test Steps:

- 1. MAKE (IUT enter mode functioning as a BBMD implementation)
- 2. MAKE (Broadcast Distribution Table = (its own entry and entries for at least 5 other BBMDs))
- 3. TRANSMIT Read- Broadcast-Distribution-Table
- 4. RECEIVE Read-Broadcast-Distribution-Table-Ack,

'List of BDT Entries' = (the table as configured, in any order)

# 14.3.X3 BBMD\_Broadcast\_Distribution\_Table Holds at Least 5 Entries

Reason For Change: NM-BBMDC-B specifically mandates this capacity behavior is supported by the product.

Purpose: Verify that the IUT supports at least 5 peer BBMD entries in its broadcast distribution table.

Test Concept: Fill the BBMD\_Broadcast\_Distribution\_Table with at least five distinct peer BBMDs entries (in addition to the entry containing the address of itself in the table).

Configuration Requirements: the IUT is configured to operate as a BBMD.

Test Steps:

- 1. WRITE BBMD Broadcast Distribution Table = (its own entry and entries for at least 5 other BBMDs)
- 2. MAKE (that configuration active)
- 3. TRANSMIT Read- Broadcast-Distribution-Table
- 4. RECEIVE Read-Broadcast-Distribution-Table-Ack,

'List of BDT Entries' = (the table as configured, in any order)

[Network Port Object Tests]
[In BTL Specified Tests, add test into 14.6]

#### 14.6 Foreign Device Management

# 14.6.X1 Holds at Least 5 Foreign Device Registrations

Reason For Change: NM-BBMDC-B specifically mandates this capacity behavior is supported by BBMDs.

Purpose: Verify that when configured to accept foreign device registrations, the IUT supports at least five simultaneous foreign device registrations.

Test Concept: The IUT is configured to support foreign device registrations. Five Register-Foreign-Device requests are sent from 5 different devices, to verify that it supports five registrations simultaneously in the FDT.

Configuration Requirements: Set BBMD\_Accept\_FD\_Registrations in the Network Port object representing the port operating as a BBMD to TRUE. The TD will be configured to emulate 5 devices.

Test Steps:

```
1. REPEAT X = 1 to 5 {
    TRANSMIT Register-Foreign-Device
    SOURCE = (device X)
    'Time-to-Live' = (a value longer than the length of the test)
    RECEIVE BVLC-Result,
    'Result Code' = Successful completion
}
```

# 14.6.X2 Negative Foreign Device Registration when FD\_Supported is FALSE

Reason For Change: The standard specifically mandates that BBMD\_Accept\_FD\_Registrations property is writable if present in BBMDs.

Purpose: Verify that when BBMD\_Accept\_FD\_Registrations is configured as FALSE, the BBMD will accept no more foreign device registrations.

Test Concept: The IUT is configured with BBMD\_Accept\_FD\_Registrations property as FALSE. Then it is verified that no more Register-Foreign-Device registrations succeed, though those already in the FDT operate as normal.

Configuration Requirements: BBMD\_Accept\_FD\_Registrations in the Network Port object representing the port is initially TRUE. If no Network Port object contains the BBMD\_Accept\_FD\_Registrations property, then this test shall be skipped.

Test Steps:

- WRITE BBMD\_Accept\_FD\_Registrations = FALSE
   TRANSMIT Register-Foreign-Device
   RECEIVE BVLC-Result,

'Result Code' = Register-Foreign-Device NAK